

Undercounter Freezer Service Manual

i.Series® and Horizon Series™



Model Group	i.Series	Horizon Series
Plasma Freezer	iPF105 (Version A)	HPF105 (Version A)
Laboratory Freezer	iLF105 (Version A)	HLF105 (Version A)

HELMER SCIENTIFIC
14400 Bergen Boulevard
Noblesville, IN 46060 USA



PH +1.317.773.9073
FAX +1.317.773.9082
USA and Canada 800.743.5637



Document History

Revision	Date	CO	Supersession	Revision Description
D	10 MAR 2014*	9160	D supersedes A, B, C	Revised layout for ease of navigation and locating information.

* Date submitted for Change Order review. Actual release date may vary.

Contents

Section I: General Information	6
1 About this Manual	6
1.1 Intended Audience	6
1.2 Model References	6
1.3 Copyright and Trademark	6
2 Safety	6
2.1 Safety Definitions	6
2.2 Product Labels	7
2.3 Avoiding Injury	7
3 Configuration	8
3.1 Model and Input Power	8
3.2 Control System	8
3.2.1 i.Series Control System	8
3.2.2 Horizon Series Control System	9
3.3 Temperature Probes	9
3.3.1 Fill Temperature Probe Bottle	9
3.3.2 Install Additional Probe Through Rear Port	9
3.4 Chart Recorder	10
3.4.1 Chart Recorder Access	10
3.4.2 Install Chart Paper	10
4 Alarm Reference	11
5 Compliance	11
5.1 Regulatory Compliance	11
5.2 WEEE Compliance	11
6 Warranty	12
6.1 Rel.i™ Product Warranty USA and Canada	12
6.1.1 Rapid Resolution	12
6.1.2 Compressor	12
6.1.3 Parts	12
6.1.4 Labor	12
6.1.5 Additional Warranty Information	12
5.2 Outside of USA and Canada	13
Section II: i.Series® Models	14
7 Product Configuration	14
7.1 Install Battery for Backup Power	14
7.2 External Monitoring Devices	14
7.2.1 Connect to Remote Alarm Interface	15
7.3 Automatic Defrost Cycle	15
7.3.1 Set the Time on the Independent Temperature Controller	16
7.3.2 Set Scheduled Defrost Times	16
7.4 Move Drawers, Shelves, and Baskets	17
7.5 Move Slides and Brackets	18
7.6 Level the Freezer	18
7.7 Optional Adapter Kits for Medication Dispensing Locks	19

7.8	Reverse Door Hinge and Handle	19
7.8.1	Remove the Door and Hinges	19
7.8.2	Reinstall the Door and Hinges	20
7.9	Stacked Undercounter Units	23
8	Temperature Monitor Settings	23
8.1	Home Screen	23
8.1.1	Home Screen Functions	23
8.2	Main Screen	24
8.3	Temperature Graph	25
8.3.1	Enable or Disable the Temperature Graph	25
8.4	Change Configuration Password	26
8.5	Calibrate Chamber Temperature Probe	26
8.6	Factory Default Settings	27
8.7	Restore Factory Default Settings	27
8.8	Alarm Settings	28
8.8.1	Alarm Volume	28
8.8.2	Alarm Pulse	28
8.8.3	High Chamber Temperature Alarm	28
8.8.4	Low Chamber Temperature Alarm	29
8.8.5	Condenser Temperature Alarm	29
8.8.6	Door Ajar Alarm	29
8.8.7	Power Failure Alarm	30
8.8.8	Chart Paper Alarm	30
8.9	Test Alarms	31
8.9.1	Automatic Chamber Temperature Alarm Test	31
8.9.2	Manual Chamber Alarm Test	32
8.9.3	Power Failure Alarm Test	32
8.9.4	Door Ajar Alarm Test	33
8.9.5	No Battery Alarm Test	33
8.10	Additional System Settings	33
8.10.1	Screen Contrast	33
8.10.2	Date and Time	34
8.10.3	Display Language	34
8.10.4	Temperature Units	35
8.11	Event Log	35
8.11.1	Event Details	36
8.12	Defrost Log	36
8.13	Upgrade System Firmware	38
8.14	Reset the i.Center Monitoring System	38
8.15	View Manufacturer and Product Information	38
9	Temperature Controller Setpoints	38
9.1	Change the Freezer Setpoint	38
9.2	Change the Control Sensor Offset	39
9.3	Change the Hysteresis Value	39
10	Maintenance	40
10.1	Recharge Refrigerant	40
10.2	Test Monitoring System Backup Batteries	40
10.3	Replace Monitoring System Backup Batteries	41

10.4	Clean the Freezer	41
10.4.1	Condenser Grill	41
10.4.2	Exterior	41
10.4.3	Interior	41
10.4.4	Door Gaskets	41
10.5	Defrost the Unit Cooler	42
10.6	Unit Cooler Cover Removal and Installation	42
10.6.1	Remove the Unit Cooler Cover	43
10.6.2	Install the Unit Cooler Cover	43
10.7	Supplies	44
11	Troubleshooting	44
11.1	General Operation Problems	44
11.2	Chamber Temperature Problems	45
11.3	Alarm Activation Problems	46
11.4	Testing Problems	48
11.5	Condensation Problems	49
12	Parts	50
12.1	Front	50
12.1.1	Monitoring System	50
12.1.2	i.Center Display Parts	51
12.1.3	Lower Panel	52
12.2	Rear	53
12.2.1	Electrical Tray	54
12.3	Interior	55
12.3.1	Unit Cooler	56
12.4	Door Hinges	57
12.5	Side Access Panel	58
13	Schematics	59
13.1	i.Series Schematic	59
14	i.Center Screen Reference	60
Section III: Horizon Series™ Models		62
15	Product Configuration	62
15.1	Install Battery for Backup Power	62
15.2	External Monitoring Devices	62
15.2.1	Connect to Remote Alarm Interface	63
15.3	Schedule Defrost Events	63
15.3.1	Set Current Time	64
15.3.2	Set Defrost Time	64
15.3.3	Schedule a Defrost Event	64
15.4	Move Drawers, Shelves, and Baskets	65
15.5	Move Slides and Brackets	66
15.6	Level the Freezer	66
15.7	Optional Adapter Kits for Medication Dispensing Locks	67
15.8	Reverse Door Hinge and Handle	67
15.8.1	Remove the Door and Hinges	67
15.8.2	Reverse the Cable Routing in the Door	69
15.8.3	Reinstall the Door and Hinges	71
15.9	Stacked Undercounter Units	74

16 Settings	75
16.1 Monitor and Controller Interface	75
16.2 Freezer Setpoint	76
16.3 Temperature Alarm Setpoints	76
16.3.1 High Temperature Alarm	77
16.3.2 Low Temperature Alarm	77
16.4 Temperature Calibration Setpoints	77
16.4.1 Monitor Offset	77
16.4.2 Control Sensor Offset	78
16.4.3 Hysteresis	78
16.5 Test Alarms	79
16.5.1 Chamber Temperature Alarm	79
16.5.2 Power Failure Alarm	79
16.5.3 Door Open Alarm	79
17 Maintenance	80
17.1 Recharge Refrigerant	80
17.2 Test Monitoring System Battery	80
17.3 Clean the Freezer	81
17.3.1 Condenser Grill	81
17.3.2 Exterior	81
17.3.3 Interior	81
17.3.4 Door Gaskets	81
17.4 Unit Cooler Cover Removal and Installation	81
17.4.1 Remove the Unit Cooler Cover	82
17.4.2 Install the Unit Cooler Cover	83
17.5 Supplies	83
18 Troubleshooting	84
18.1 General Operation Problems	84
18.2 Chamber Temperature Problems	84
18.3 Alarm Activation Problems	85
18.4 Condensation Problems	87
19 Parts	88
19.1 Front	88
19.1.1 Control System Display	88
19.1.2 Control and Monitoring	89
19.1.3 Lower Panel	89
19.2 Rear	90
19.2.1 Electrical Tray	91
19.3 Interior	92
19.3.1 Unit Cooler	93
19.4 Door Hinges	94
19.5 Side Access Panel	95
20 Schematics	96
20.1 Horizon Series Schematic	96

Section I: General Information

1 About this Manual

1.1 Intended Audience

This manual is intended for use by end users of the freezer and authorized service technicians.

1.2 Model References

Generic references are used throughout this manual to group models that contain similar features. For example, “105 models” refers to all models of that size (iPF105, HPF105, iLF105, HLF105). This manual covers all undercounter freezers, which may be identified singly, by their size, or by their respective “Series.”

1.3 Copyright and Trademark

Helmer®, i.Series®, i.Center™, Horizon Series™, and Rel.i™ are registered trademarks or trademarks of Helmer, Inc. in the United States of America. Copyright © 2014 Helmer, Inc. All other trademarks and registered trademarks are the property of their respective owners.

Helmer, Inc., doing business as (DBA) Helmer Scientific and Helmer.

2 Safety

The operator or technician performing maintenance or service on Helmer Scientific products must (a) inspect the product for abnormal wear and damage, (b) choose a repair procedure which will not endanger his/her safety, the safety of others, the product, or the safe operation of the product, and (c) fully inspect and test the product to ensure the maintenance or service has been performed properly.

2.1 Safety Definitions

The following general safety alerts appear with all safety statements within this manual. Read and abide by the safety statement that accompanies the safety alert symbol.



WARNING The safety statement that follows this safety alert symbol indicates a hazardous situation which, if not avoided, could result in serious injury.



CAUTION The safety statement that follows this safety alert symbol indicates a hazardous situation which, if not avoided, could result in minor or moderate injury.



NOTICE The safety statement that follows this safety alert symbol indicates a situation which, if not avoided, could result in damage to the product or stored inventory.

2.2 Product Labels



Caution: Risk of damage to equipment or danger to operator



Caution: Hot surface



Caution: Shock/electrical hazard



Caution: Unlock all casters



Earth / ground terminal



Protective earth / ground terminal

2.3 Avoiding Injury

- ▶ Review safety instructions before installing, using, or maintaining the equipment.
- ▶ Before moving unit, ensure door is closed and casters (if installed) are unlocked and free of debris.
- ▶ Before moving unit, disconnect the AC power cord and secure the cord.
- ▶ Never physically restrict any moving component.
- ▶ Avoid removing electrical service panels and access panels unless so instructed.
- ▶ Keep hands away from pinch points when closing the door.
- ▶ Avoid sharp edges when working inside the electrical compartment and refrigeration compartment.
- ▶ Ensure biological materials are stored at recommended temperatures determined by standards, literature, or good laboratory practices.
- ▶ Proceed with caution when adding and removing samples from the freezer.
- ▶ Use supplied power cord only.
- ▶ Using the equipment in a manner not specified by Helmer Scientific may impair the protection provided by the equipment.
- ▶ Decontaminate parts prior to sending for service or repair. Contact Helmer Scientific or your distributor for decontamination instructions and a Return Authorization Number.
- ▶ Ensure biological materials are stored safely, in accordance with all applicable organizational, regulatory, and legal requirements.
- ▶ The freezer is not considered to be a storage cabinet for flammable or hazardous materials.

3 Configuration

3.1 Model and Input Power

NOTE Service information varies depending on the model and power requirements.

This information appears on the product specification label, located on the rear of the freezer. The model also appears on a label located in the chamber on the upper side of the right wall.



Left: Chamber label. Right: Product specification label.

Label	Description
A	Model (REF)
B	Serial number (SN)
C	Version
D	Power requirements

3.2 Control System

NOTE Service information varies depending on the control system.

Helmer freezers have one of two control systems installed. The type of control system varies by model.

3.2.1 i.Series Control System

i.Series freezers are equipped with the i.Center monitoring system and independent temperature controller.



i.Center monitor.



Independent temperature controller.

3.2.2 Horizon Series Control System

Horizon Series freezers feature the Horizon combined monitor and temperature controller. The Horizon Series system controls chamber temperature and monitors and displays operational information.



Horizon Series combined monitoring and control system (user interface).

3.3 Temperature Probes

Number and location of probes varies by model. External probes may be introduced through existing rear port and immersed in existing probe bottle.

For each probe bottle, use:

- ▶ Approximately 4 oz. (120 mL) of product simulation solution (1:1 ratio of water to propylene glycol or equivalent low-temperature fluid).



Left: Probe bottle with temperature probe. Right: Access port on rear of freezer.

3.3.1 Fill Temperature Probe Bottle



NOTICE Temperature probes are fragile; handle with care.

- 1 Remove all probes from bottle and remove bottle from bracket.
- 2 Remove cap and fill with approximately 4 oz. (120 mL) of product simulation solution.
- 3 Install cap and place bottle in bracket.
- 4 Replace probes, immersing at least 2" (50 mm) in solution.

3.3.2 Install Additional Probe Through Rear Port

- 1 Peel back putty to expose port.
- 2 Insert probe through port into chamber.
- 3 Insert probe into bottle.
- 4 Replace putty, ensuring a tight seal.

3.4 Chart Recorder

If installed, refer to the Temperature Chart Recorder Operation and Service Manual on CD.


The chart recorder has a battery system, enabling a period of continuous operation if power is lost. Battery life varies by manufacturer as well as voltage level remaining. Providing full power is available, backup power for the temperature chart recorder is available for up to 14 hours.

Prior to use:

- ▶ Connect the chart recorder to AC power.
- ▶ Install battery.
- ▶ Add paper.
- ▶ Install the chart recorder probe in the probe bottle.
- ▶ Calibrate chart recorder to match chamber temperature.

3.4.1 Chart Recorder Access

Open door by pulling door open.



3.4.2 Install Chart Paper

- 1 Press and hold **C** button. When stylus begins to move left, release button. The LED flashes to indicate current temperature range.
- 2 When stylus stops moving, remove chart knob then move knob up and away.
- 3 Place chart paper on chart recorder.
- 4 Gently lift stylus and rotate paper so current time line corresponds to time line groove.



- 5 Hold chart paper and reinstall chart knob.

NOTE For accurate temperature reading, ensure that current time is aligned with time line groove when chart knob is tightened.

- 6 Confirm temperature range is set to the correct value.
- 7 Press and hold **C** button. When stylus begins to move right, release button.
- 8 Confirm stylus is marking temperature correctly.

4 Alarm Reference

If an alarm condition is met, an alarm activates. Some alarms are visual only; others are visual and audible. Some alarms are sent through the remote alarm interface.

The table indicates if an alarm is audible (A), visual (V), or sent through the remote alarm interface (R).

Alarm	Alarm Type
High Temperature	A, V, R
Low Temperature	A, V, R (Horizon Series)
Compressor Temperature	A, V, R (i.Series)
Door Open (Time)	A, V, R
Power Failure	A, V, R
Low Battery	V (i.Series)
No Battery	A, V, R (i.Series)
Probe Failure	A, V, R
Chart paper	V (i.Series)

5 Compliance

5.1 Regulatory Compliance

This device complies with the requirements of directive 93/42/EEC concerning Medical Devices, as amended by 2007/47/EC.

Sound level is less than 70 dB(A).



Emergo Europe
Molenstraat 15
2513 BH
The Hague, Netherlands

5.2 WEEE Compliance

The WEEE (waste electrical and electronic equipment) symbol (right) indicates compliance with European Union Directive WEEE 2002/96/EC and applicable provisions. The directive sets requirements for labeling and disposal of certain products in affected countries.



When disposing of this product in countries affected by this directive:

- ▶ Do not dispose of this product as unsorted municipal waste.
- ▶ Collect this product separately.
- ▶ Use collection and return systems available locally.

For more information on the return, recovery, or recycling of this product, contact your local distributor.

6 Warranty

6.1 Rel.i™ Product Warranty USA and Canada

For technical service needs, please contact Helmer at 800-743-5637 or www.helmerinc.com. Have the model and serial number available when calling.

6.1.1 Rapid Resolution

When a warranty issue arises it is our desire to respond quickly and appropriately. The service department at Helmer is there for you. Helmer will oversee the handling of your warranty service from start to finish. Therefore, Helmer must give advance authorization for all service calls and/or parts needs relating to a warranty issue. Any repeat service calls must also be authorized as well. This allows for proper diagnosis and action. Helmer will not be responsible for charges incurred for service calls made by third parties prior to authorization from Helmer. Helmer retains the right to replace any product in lieu of servicing it in the field.

6.1.2 Compressor

For the warranty period listed below, Helmer will supply the refrigeration compressor, if it is determined to be defective, at no charge, including freight. Helmer will not be liable for installation, refrigerant, or miscellaneous charges required to install the compressor beyond the first year of the warranty period.

- ▶ i.Series model compressor warranty period is five (5) years.
- ▶ Horizon Series model compressor warranty period is three (3) years.

6.1.3 Parts

For a period of two (2) years, Helmer will supply at no charge, including freight, any part that fails due to defects in material or workmanship under normal use, with the exception of expendable items. Expendable items such as glass, filters, light bulbs, and door gaskets are excluded from this warranty coverage. Inspection of defective parts by Helmer will be final in determining warranty status. Warranty procedures must be followed in all events.

6.1.4 Labor

For a period of one (1) year, Helmer will cover repair labor costs (including travel) and the cost of refrigerant and supplies necessary to perform authorized repairs. Repair service must be performed by an authorized Helmer service agency following the authorization process detailed above. Alternatively, your facility's staff may work with a Helmer technician to make repairs. Labor costs for repairs made by unauthorized service personnel, or without the assistance of a Helmer technician, will be the responsibility of the end user.

6.1.5 Additional Warranty Information

The time periods set forth above begin two (2) weeks after the original date of shipment from Helmer. Warranty procedures set forth above must be followed in all events.

THERE ARE NO WARRANTIES WHICH EXTEND BEYOND THE DESCRIPTION ON THE FACE HEREOF. THIS WARRANTY IS EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. NO WARRANTIES OF MERCHANTABILITY OR FITNESS FOR PARTICULAR PURPOSE SHALL APPLY.

THE LIABILITY, IF ANY, OF HELMER FOR DIRECT DAMAGES WHETHER ARISING FROM A BREACH OF ANY SALES AGREEMENT, BREACH OF WARRANTY, NEGLIGENCE, OR INDEMNITY, STRICT LIABILITY OR OTHER TORT, OR OTHERWISE WITH RESPECT TO THE GOODS OR ANY

SERVICES IS LIMITED TO AN AMOUNT NOT TO EXCEED THE PRICE OF THE PARTICULAR GOODS OR SERVICES GIVING RISE TO THE LIABILITY. IN NO EVENT SHALL HELMER BE LIABLE FOR ANY INDIRECT, INCIDENTAL, CONSEQUENTIAL, OR SPECIAL DAMAGES, INCLUDING WITHOUT LIMITATION DAMAGES RELATED TO LOST REVENUES OR PROFITS, OR LOSS OF PRODUCTS.

This warranty does not cover damages caused in transit, during installation by accident, misuse, fire, flood, or acts of God. Further, this warranty will not be valid if Helmer determines that the failure was caused by a lack of performing recommended equipment maintenance (per Helmer manual) or by using the product in a manner other than for its intended use. Installation and calibration are not covered under this warranty agreement.

5.2 Outside of USA and Canada

Consult your local distributor for warranty information.

Section II: i.Series® Models

7 Product Configuration

7.1 Install Battery for Backup Power

The monitoring system and chart recorder each have a battery system, enabling a period of continuous operation if power is lost.


NOTE The monitoring system will not start on battery power alone. If the freezer was previously not connected to AC power and the batteries are installed, the monitoring system will not run on battery power.

Battery life varies by manufacturer as well as voltage level remaining. Providing full power is available and no battery-related alarms are active, backup power for the monitoring system is available for up to two hours.



NOTICE When installing replacement batteries, use only batteries which meets the specifications outlined in chapter 10.7 (Supplies).

The batteries are located below the chamber, behind the front cover.



Monitoring system backup batteries.

Five batteries are installed and one battery is included in the accessory package. Install the sixth battery to provide power to the monitoring system in the event of an AC power failure.

7.2 External Monitoring Devices



CAUTION

- ▶ The interface on the remote alarm monitoring system is intended for connection to the end user's central alarm system(s) that uses normally-open or normally-closed dry contacts.
- ▶ If an external power supply exceeding 30 V (RMS) or 60 V (DC) is connected to the remote alarm monitoring system's circuit, the remote alarm will not function properly; may be damaged; or may result in injury to the user.

NOTE In the event of a power failure, the power failure alarm condition is transmitted through the remote alarm contacts.

The remote alarm interface is a relay switch with three terminals:

- ▶ Common (COM)
- ▶ Normally Open (NO)
- ▶ Normally Closed (NC)

Terminals are dry contacts and do not supply voltage. Interface circuit is either normally open or normally closed, depending on terminals used. Requirements for your alarm system determine which alarm wires must connect to terminals.

- ▶ 0.5 A at 125 V (AC): 1 A at 250 V (DC)

7.2.1 Connect to Remote Alarm Interface

- 1 Switch AC ON/OFF switch **OFF**. Remove one battery from the monitoring system backup battery holder.
- 2 On back of freezer, locate the remote alarm terminals.
- 3 Connect remote alarm wires to appropriate terminals, according to requirements for your alarm system.
- 4 Use a cable tie to relieve strain on alarm wires (as necessary).
- 5 Reinstall the battery in the monitoring system backup battery holder. Switch AC ON/OFF switch **ON**.
- 6 Touch **MUTE** to disable the high temperature alarm while freezer reaches operating temperature.

7.3 Automatic Defrost Cycle

The number of programmed defrost events is dependent on environmental conditions and the frequency of usage. The recommended number of daily defrost cycles is three to four, at even intervals. Defrost events should take place when the freezer door is opened infrequently.

NOTE Depending on the high temperature alarm setpoint and the actual temperature increase during the defrost cycle, frequent door openings may trigger repeated high temperature alarms.

The independent temperature controller is located inside the lower front panel of the freezer. The controller can execute a maximum of four defrost events per day. Specify the number of defrost events per day and the execution times. The timing is based on the current time setting on the independent temperature controller.



Independent temperature controller.

Defrost Event	On/Off	Default Time
1	On	12:00 AM
2	On	8:00 AM
3	On	4:00 PM
4	Off	-

7.3.1 Set the Time on the Independent Temperature Controller

- NOTE**
- ▶ The current time on the independent temperature controller should be set to match the time on the i.Center monitoring system.
 - ▶ To change the value for a parameter, first enter the program mode for that level.
 - ▶ When there is no interaction for four minutes, the temperature controller exits program mode and returns to normal mode.

Defrost event times are based on the current time setting on the temperature/defrost controller. The current time is controlled by two parameters: P34 and P35.

Parameter	Description	Range
P34	Hour setting for current time (24-hour format)	00 (midnight) to 23
P35	Minute setting for current time	00 to 59

Set the current time:

- 1 On the independent temperature controller, press the **P** button to access the parameter menu.
 - ▶ “PXX” is displayed, where “XX” is a parameter number.
- 2 Select the **Hour** parameter (P34).
 - a Press the **UP** or **DOWN** arrow buttons until “P34” is displayed.
 - b Press the **P** button.
 - c The current hour setting is displayed in 24-hour time. Example: 2 PM is displayed as “14”.
- 3 Change the **Hour** parameter.
 - a Press the **UP** or **DOWN** arrow buttons until the desired hour is displayed.
- 4 Press the **P** button.
 - ▶ The setting is changed and “P34” is displayed.
- 5 Select the **Minute** parameter (P35).
 - a Press the **UP** or **DOWN** arrow buttons until “P35” is displayed.
 - b Press the **P** button.
 - c The current minute setting is displayed. Example: 2 PM is displayed as “14”.
- 6 Change the **Minute** parameter.
 - a Press the **UP** or **DOWN** arrow buttons until the desired minute is displayed.
- 7 Press the **P** button.
 - ▶ The **Hour** and **Minute** parameters are changed and “P35” is displayed.
- 8 Exit program mode.
 - a Press the **UP** or **DOWN** arrow buttons until “P01” is displayed, or
 - b Do not press any buttons for four minutes. Parameter 01 (“P01”) is displayed.

7.3.2 Set Scheduled Defrost Times

Defrost event times are controlled by four parameters: P24, P25, P26 and P27.

Parameter	Description	Range	Default Setting
P24	Defrost event 1 time	000 to 235, or OFF	000
P25	Defrost event 2 time	000 to 235, or OFF	080
P26	Defrost event 3 time	000 to 235, or OFF	160
P27	Defrost event 4 time	000 to 235, or OFF	OFF

Each parameter is set either to OFF (indicating that the defrost event is disabled), or a three-digit number (representing the time of the defrost event).

- ▶ The first two digits represent the hour in 24-hour format.
- ▶ The third digit represents the minute, in 10-minute intervals.

- NOTE**
- ▶ 16X represents 4 PM
 - ▶ XX2 represents 20 minutes
 - ▶ 162 represents 4:20 PM
 - ▶ 000 represents midnight

The defrost event time parameters are restricted through an access code. To view and change these parameter settings, the access code (the last parameter) must first be set to **88**.

Set the defrost time

- 1 Ensure that the current time programmed in the independent temperature controller is correct and matches the time programmed in the i.Center monitoring system. Change the time if necessary.
- 2 Enter the access code.
 - a Press the **UP** or **DOWN** arrow buttons until the last parameter is displayed.
 - b Press the **P** button. The parameter is displayed.
 - c Press the **UP** or **DOWN** arrow buttons to change the parameter to **88**.
 - d Press the **P** button. The setpoint is changed and the last parameter is displayed.
- 3 Select the defrost time parameter setting (P24, P25, P26, or P27).
 - a Press the **UP** or **DOWN** arrow buttons to display the desired defrost parameter.
 - b Press the **P** button. The current setting is displayed.
- 4 Press the **UP** or **DOWN** arrow buttons to adjust the setting for the selected parameter.
- 5 Press the **P** button. The setting is changed and the parameter is displayed.
- 6 Repeat steps 3-5 for additional defrost parameters.

7.4

Move Drawers, Shelves, and Baskets



Storage features.



- CAUTION**
- ▶ Keep hands away from pinch points when closing the door.
 - ▶ Before moving drawers, ensure they are completely empty for safe lifting.
 - ▶ Maximum basket, drawer, or shelf load is 100 lbs (46 kg).



- NOTICE** Before moving storage components, protect stored items in freezer from extended exposure to adverse temperature.

Remove a drawer or basket:

- 1 Pull drawer or basket out until it stops.
- 2 Tilt the front of the drawer or basket upward.
- 3 Pull drawer or basket free of the slides.

Install a drawer or basket:

- 1 Tilt the front of the drawer or basket upward.
- 2 Set the wheels on the drawer or basket in the slides in the cabinet.
- 3 Lower the front of the drawer.
- 4 Gently push the drawer or basket into the chamber until it stops.
- 5 Pull drawer or basket out until it stops; check for smooth operation.

Remove a shelf:

- 1 With one hand, lift front edge of the shelf from the front brackets.
- 2 With the other hand, reach under the shelf and bump rear edge of the shelf upward to disengage rear brackets.

Install a shelf:

- 1 Insert shelf into chamber, placing it on brackets.
- 2 Gently bump rear edge of the shelf downward to engage brackets.
- 3 Pulling shelf forward gently; shelf should not disengage from rear brackets.

7.5**Move Slides and Brackets****Remove drawer slides:**

- 1 Using a screwdriver, remove front bracket retainers.
- 2 Tap front brackets upward to disengage standards.
- 3 Remove slides from standards.

Install drawer slides:

- 1 Insert slides into standard at appropriate height.
- 2 Tap front brackets downward to engage standards.
- 3 Using a screwdriver, install front bracket retainers.

Remove shelf brackets:

- 1 Using a screwdriver, remove front bracket retainers.
- 2 Tap front brackets upward to disengage standards.
- 3 Remove front brackets from standards.

Install shelf brackets:

- 1 Insert front brackets into standard at appropriate height.
- 2 Tap front brackets downward to engage standards.
- 3 Using a screwdriver, install front bracket retainers.

7.6**Level the Freezer****NOTE**

- ▶ Leveling feet are optional.
- ▶ Helmer recommends the use of leveling feet.
- ▶ A bubble level may be used to ensure the freezer is level.

Leveling feet must be adjusted to provide unit cooler drainage.

Front-to-back:

- 1 Rotate the leveling feet to raise or lower leveling feet.
- 2 When freezer is properly leveled, bottom of the unit cooler will slope downward from front to back (toward the condensate drain line).

Side-to-side:

- 1 Rotate the leveling feet to raise or lower leveling feet.
- 2 When freezer is properly leveled, bottom of the unit cooler will be horizontal (parallel to the floor).

7.7 Optional Adapter Kits for Medication Dispensing Locks

Contact Helmer Technical Service or your distributor for service documentation pertaining to medication dispensing locks.

7.8 Reverse Door Hinge and Handle



NOTICE Before reversing door hinge and handle, protect stored items in freezer from extended exposure to adverse temperature.

NOTE Freezer must be on the floor or on an elevated work surface with enough space in front of the freezer to lay the door face-down for disassembly.


7.8.1 Remove the Door and Hinges

- 1 Open the lower front control panel. Switch AC ON/OFF switch **OFF**. Remove one battery from the backup battery holder.
- 2 Remove the door handle assembly.
 - a Remove four screws holding the door handle assembly on the door.
 - b Set the door handle assembly aside.



Door handle assembly.

- 3 Remove door latch / door catch.
 - a Remove two screws holding the door latch plates and spacer bar on the cabinet.
 - b Set the latch plates and spacer bar aside.



Door latch plate.


- 4 With the door shut, remove the cover plate from both hinges.
- 5 Remove the spring assembly from the lower hinge.
 - a Use a J-hook tool to engage the left-most hole in the spring cap and rotate the spring cap from *left to right*, and hold.
 - b Remove the pin from the spring cap.
 - c Allow the spring to relax.
 - d Use a J-hook tool to engage any hole in the spring cap compress spring downward.
 - e Remove spring assembly from the lower hinge.
 - f Set the spring assembly aside.



NOTICE A second person should assist by supporting the door while the hinges are removed.

NOTE The two screws holding the hinge on the door are longer than the three screws holding the hinge on the cabinet. The screws must be installed in the same location when moving the hinge to the opposite side of the door.

- 6 Remove the lower hinge.
 - a Support the door.
 - b Remove five screws attaching the lower hinge to the door and cabinet.
 - c Remove the lower hinge.
 - d Reverse the hinge manually (as if moving the hinge from a fully-closed to a fully-open position).
 - e Set the lower hinge aside.
 - f Continue to support the door.
- 7 Remove the upper hinge.
 - a Remove five screws attaching the upper hinge to the door and cabinet.
 - b Remove the upper hinge.
 - c Reverse the hinge manually (as if moving the hinge from a fully-closed to a fully-open position).
 - d Set the upper hinge aside.




Hinge removal (lower hinge shown with spring removed).

- 8 Lay the door face-down in front of the cabinet.

7.8.2 Reinstall the Door and Hinges

- 1 Install the hinges and hinge plates on the door.
 - a Hand-thread two screws through each hinge and into the door.
 - b Leave the screws slightly loose.
 - c If a shim was used on the lower hinge, transfer the shim to the new hinge location.

NOTE Ensure that the upper and lower hinges are not interchanged when moving the hinges to the opposite side of the door.




Attach hinge to door (lower hinge shown).



NOTICE A second person should assist by supporting the door while the hinges are installed.

- 2 Install the door on the cabinet.
 - a Lift the door to the cabinet.
 - b Align the holes in the hinges with the corresponding holes in the cabinet.
 - c Hand-thread three screws through each hinge and into the cabinet.
 - d Do not allow the weight of the door to rest on the hinges.




Attach hinge to cabinet (lower hinge shown).


- 3 Align the door and tighten screws.
 - a Support the door so the top edge of the door is level.
 - b Level the door using a shim if necessary.
 - c Tighten all screws attaching both hinges to the door and to the cabinet.

NOTE If a shim is necessary to level the door after hinge reversal, contact Helmer Technical Service to obtain a shim.


- 4 Install the door handle on the opposite side of the door.
- 5 Install the latch plates and spacer bar on the opposite side of the cabinet.
- 6 Install the hinge spring and pin assembly.
 - a Close the door.
 - b Assemble the hinge spring assembly for the left side of the door (*Figure A*).
 - c Orient the bend in the coil toward the front of the freezer (*Figure B*).
 - d Slide the internal hex cap (with washer) on to the upper hex bolt in the lower hinge.



- e Use a J-hook tool in the spring cap to compress the spring upward (*Figure C*).
- f While compressing the spring, slide the spring cap over the lower hex bolt in the lower hinge (*Figure D*).



- g Use a J-hook tool to engage the right-most hole in the spring cap and rotate the spring cap from *right to left*, and hold.
- h Count four holes, starting from and including the spring cap hole closest to the end of the coil.
- i Insert the pin in the fourth hole.



Rotate the spring using a J-hook tool then insert pin (left-hinged door shown).

- 7 Switch AC ON/OFF switch **ON**. Reinstall the battery in the backup battery holder.
- 8 Verify the door is level and the hinges operate smoothly and the door seals tightly.
- 9 Press the **MUTE** button to disable the high temperature alarm while freezer reaches operating temperature.

7.9 Stacked Undercounter Units



- WARNING**
- ▶ For a stacked configuration, both units must have leveling feet installed.
 - ▶ The back brace bars and front stabilizing brackets must be installed.
 - ▶ When stacking a refrigerator and freezer (104 and/or 105 models), place the heavier unit on the bottom.
 - ▶ Do not open multiple, loaded drawers or baskets at the same time.


Call Helmer or your distributor for more information on the stacking kit, and for methods to secure both units to the wall and/or the floor.

8 Temperature Monitor Settings

8.1 Home Screen

The HOME screen appears when:

- ▶ The **HOME** button is pressed from any other screen
- ▶ There is no interaction for two minutes on any screen other than those used to enter a password



HOME screen on the monitoring system.

Label	Description	Label	Description
A	Screen name	E	Buttons
B	Battery voltage level	F	Date and time display
C	Chamber temperature display	G	Defrost icon
D	Button labels		

8.1.1 Home Screen Functions

NOTE Refer to chapter 14 (i.Center Screen Reference) for a complete list of screens in the i.Center monitoring system.

- ▶ View current temperature readings
- ▶ View the current time and date
- ▶ View detailed information about current or previous alarm events
- ▶ View the remaining backup battery charge
- ▶ View active alarms
- ▶ Mute audible alarms
- ▶ Adjust contrast
- ▶ View 24-hour chamber temperature graph
- ▶ Access Main screen to view and change settings

8.2 Main Screen

The Main screen displays functional options that allow access to all other screens in the system.




MAIN screen functional options.

Functions available from the Main screen:

Option	Function
Event Log	<ul style="list-style-type: none"> ▶ View historical information about alarms and operational events
System Alarm Test and Status	<ul style="list-style-type: none"> ▶ Start or stop an automatic test for temperature alarms ▶ View the number of days remaining before the paper for the temperature chart recorder needs to be changed ▶ View the current status of the door (OPEN or CLOSED) ▶ View the current condenser temperature
Edit Configuration (password required)	<ul style="list-style-type: none"> ▶ Change the language used for text ▶ Change date and time information ▶ Change temperature units ▶ Change the volume and pattern for audible alarms ▶ Enable or disable the chart paper timer ▶ Enable or disable the temperature graph display ▶ Change alarm-related setpoints and timers ▶ Calibrate the temperature probe reading ▶ Change some settings to the factory default values ▶ Change the password, preventing unauthorized changes
View Configuration	<ul style="list-style-type: none"> ▶ View the date and time formats ▶ View alarm-related setpoints and timers ▶ View the volume and pattern for audible alarms ▶ View the setting for the chart paper timer ▶ View the setting for the temperature graph display ▶ View the settings for temperature and time alarms
Product/Company Information	<ul style="list-style-type: none"> ▶ View the software versions for control and display components of the monitoring system ▶ View information to contact Helmer
i.Help	<ul style="list-style-type: none"> ▶ Access the on-board help system

8.3 Temperature Graph



The Temperature Graph screen appears when:

- ▶ The Temperature Graph feature is enabled
- ▶ There is no interaction for one minute on any screen
- ▶ There are no active alarms

NOTE: While there is power to the monitoring system, data from the chamber temperature probe is collected real-time, and the past 24 hours of collected data is stored and displayed.

In the event of an AC power failure, the monitoring system continues to collect and display temperature data as long as battery power is available. If AC power is restored before battery power fails, there is no interruption in data collection. The temperature that is displayed on the graph for eight hours earlier was the temperature eight hours ago.

If battery power fails, the monitoring system stops displaying temperature data and stops collecting new temperature data. The past 24 hours of data temperature data is retained. When AC power is restored, the stored data is displayed, and the monitor resumes collecting and displaying real-time temperature data. In this case, there is an interruption in data collection: the temperature displayed on the graph for eight hours earlier was the temperature at eight hours before the backup power failed.

8.3.1 Enable or Disable the Temperature Graph

The i.Center has a real-time temperature graph which displays temperature probe readings for the past 24 hours of operation. This graph appears on the bottom of the HOME screen when no button has been pressed for one minute, and if no alarm is active. The graph clears if a button is pressed or an alarm activates.

NOTE: The temperature graph is enabled by default.

Enable or disable the temperature graph:

- 1 On the HOME screen, press the **MAIN** button.
- 2 Press the **DOWN** button to select Edit Configuration. Press the **SELECT** button.
- 3 Enter the password when prompted.
- 4 Press the **DOWN** button to select Alarm Setpoints. Press the **SELECT** button.
- 5 Press the **DOWN** button to select Temperature Graph.
- 6 Press the **INC** or **DEC** buttons to select enable or disable the temperature graph.
- 7 Press the **BACK** button to return to the Edit Configuration screen, or press the **HOME** button to exit.

8.4 Change Configuration Password

The default password is 1234. A new password must use four digits, ranging from 1 to 5.

Change the password:

- 1 On the HOME screen, press the **MAIN** button.
- 2 Press the **DOWN** button to select Edit Configuration. Press the **SELECT** button.
- 3 Enter the password when prompted.
- 4 Press the **DOWN** button to select Change Password. Press the **SELECT** button.
- 5 Enter the new password, then re-enter the new password when prompted.
 - ▶ If password entries match, the “update” message is displayed.
 - ▶ If password entries do not match, the “incorrect match” message is displayed. Repeat the procedure to change the password.

8.5 Calibrate Chamber Temperature Probe

Verify the temperature probe is reading chamber temperature correctly by comparing the chamber probe reading to temperature read by an independent thermometer. If the chamber temperature probe is not reading correctly, change the value displayed on the temperature monitoring system.

NOTE If the variance is within acceptable limits for your organization, changing probe settings is optional.

- ▶ Default setting for chamber temperature is -30.0 °C
- ▶ Value is factory-preset

Obtain:

- ▶ Independent thermometer, calibrated and traceable per national standards

Measure the chamber temperature:

- 1 Remove the probe from the probe bottle.
- 2 Unscrew the cap from the bottle.
- 3 Insert the thermometer and temperature probe in the bottle. The probe and thermometer should be immersed at least 2” (50 mm).
- 4 Close the door and allow the chamber temperature to stabilize for 10 minutes.
- 5 Observe and note the thermometer temperature.

EXAMPLE

- ▶ Measured temperature (at the probe bottle) is -30.0 °C
- ▶ Displayed temperature is -32.0 °C
- ▶ Change displayed temperature to -30.0 °C

Enter the new calibration value:

- 1 On the HOME screen, press the **MAIN** button.
- 2 Press the **DOWN** button to highlight Edit Configuration. Press the **SELECT** button.
- 3 Enter the password when prompted.
- 4 Press the **DOWN** button to highlight Temperature Calibration. Press the **SELECT** button.
 - a The Upper Probe option is displayed and the Temperature option is highlighted.
 - b Press the **INC** or **DEC** buttons to change the displayed value to match the value measured by the independent thermometer.

- 5 Press the **DOWN** button to highlight Store Calibration.
 - a To save the new value, press the **ENTER** button. The “Calibration Memorized” message appears. New settings are saved.
 - b To discard the new value, press the **BACK** button or **HOME** button to exit. New settings are not saved.
- 6 Remove thermometer and probe from bottle.
- 7 Replace the probe in probe bottle.
- 8 Replace bottle cap, ensuring a tight fit.
- 9 Place the probe in bottle, immersing at least 2” (50 mm).

NOTE

- ▶ The current temperature displayed by the monitoring system may change so that it no longer matches the new probe calibration value. This is normal.
- ▶ If a new probe value is entered but not saved, the new value will appear when the calibration setting for the probe is viewed. This is normal.

8.6 Factory Default Settings

Settings listed below may be simultaneously returned to factory default values.

NOTE The factory default settings may not be the same as the settings that were factory-calibrated before the freezer was shipped.

Setting	Restored Value
High Alarm Setpoint	-20.0 °C
Condenser Alarm Setpoint	50.0 °C
Door Ajar Timeout	3 minutes
Power Failure Timeout	3 minutes
Chart Paper Timer	6.5 days

8.7 Restore Factory Default Settings

Restore settings:

- 1 Press the **MAIN** button.
- 2 Press the **DOWN** button to highlight Edit Configuration. Press the **SELECT** button.
- 3 Enter the password when prompted.
- 4 Press the **DOWN** button to highlight Factory Default Settings. Press the **SELECT** button.
- 5 Do one of the following:
 - ▶ Press the **ENTER** button. Factory default settings are restored.
 - ▶ Press the **BACK** button. Factory default settings are not restored.

8.8 Alarm Settings

The following alarm settings may be changed by the operator. The setpoint for temperature alarms may be changed (where applicable), as well as the time delay between when the alarm condition commences and when the visual and audible alarms are initiated.

8.8.1 Alarm Volume

The alarm volume can be changed. The Alarm Volume controls volume for all audible alarms.

- ▶ Default setting is 10
- ▶ Setting can be changed from 1 to 10
- ▶ 1 is the quietest setting; 10 is the loudest setting

Change the alarm volume:

- 1 Press the **MAIN** button.
- 2 Press the **DOWN** button to highlight Edit Configuration. Press the **SELECT** button.
- 3 Enter the password when prompted.
- 4 Press the **DOWN** button to highlight System Options. Press the **SELECT** button.
- 5 Press the **DOWN** button to highlight Alarm Volume.
- 6 Press the **INC** or **DEC** buttons to change the setting.
- 7 Press the **BACK** button to return to the Edit Configuration screen, or press the **HOME** button to exit.
The new settings are saved.

8.8.2 Alarm Pulse

The alarm pattern can be changed. This is useful if several freezers with alarms are collocated, and distinguishing the source of the alarm quickly is desirable.

- ▶ Default setting is Single.
- ▶ Setting can be changed between Single, Double, Triple, and Constant.

Change the alarm pulse:

- 1 Press the **MAIN** button.
- 2 Press the **DOWN** button to highlight Edit Configuration. Press the **SELECT** button.
- 3 Enter the password when prompted.
- 4 Press the **DOWN** button to highlight System Options. Press the **SELECT** button.
- 5 Press the **DOWN** button to highlight Alarm Pulse.
- 6 Press the **INC** or **DEC** buttons to change the setting.
- 7 Press the **BACK** button to return to the Edit Configuration screen, or press the **HOME** button to exit.
The new settings are saved.

8.8.3 High Chamber Temperature Alarm

The High Alarm setpoint specifies the temperature at which the High Temperature Alarm activates. If the temperature detected by the upper chamber probe is greater than or equal to this value, the alarm activates.

- ▶ Default setpoint is -20.0 °C
- ▶ Setpoint can be changed from -40.0 °C to 0.0 °C

Change the setpoint:

- 1 Press the **MAIN** button.
- 2 Press the **DOWN** button to highlight Edit Configuration. Press the **SELECT** button.
- 3 Enter the password when prompted.
- 4 Press the **DOWN** button to highlight Alarm Setpoints. Press the **SELECT** button.
- 5 Press the **DOWN** button to highlight High Alarm Setpoint.
- 6 Press the **INC** or **DEC** buttons to change the setting.

- 7 Press the **BACK** button to return to the Edit Configuration screen, or press the **HOME** button to exit. The new settings are saved.

8.8.4 Low Chamber Temperature Alarm



NOTICE The Low Alarm Setpoint is not used in Helmer freezers.

8.8.5 Condenser Temperature Alarm

The Condenser Alarm setpoint specifies the temperature at which the Condenser Temperature Alarm activates. If the temperature of the condenser discharge line is greater than or equal to this value, the alarm activates.

- ▶ Default setpoint is 50 °C
- ▶ Setpoint can be changed from -40 °C to +80 °C



NOTICE Condenser Temperature Alarm should not be changed unless directed by Helmer Technical Service.

Change the setpoint:

- 1 Press the **MAIN** button.
- 2 Press the **DOWN** button to highlight Edit Configuration. Press the **SELECT** button.
- 3 Enter the password when prompted.
- 4 Press the **DOWN** button to highlight Alarm Setpoints. Press the **SELECT** button.
- 5 Press the **DOWN** button to highlight Cond. Alarm Setpoint.
- 6 Press the **INC** or **DEC** buttons to change the setting.
- 7 Press the **BACK** button to return to the Edit Configuration screen, or press the **HOME** button to exit. The new settings are saved.

8.8.6 Door Ajar Alarm

The Door Ajar Timeout specifies longest time the freezer door can be open before the alarm activates. If the time elapsed since the last door opening is greater than or equal to this value, the alarm activates.

- ▶ Default delay setting is three minutes
- ▶ Setting can be changed from 0 minutes to 60 minutes

Change the alarm delay:

- 1 Press the **MAIN** button.
- 2 Press the **DOWN** button to highlight Edit Configuration. Press the **SELECT** button.
- 3 Enter the password when prompted.
- 4 Press the **DOWN** button to highlight Alarm Setpoints. Press the **SELECT** button.
- 5 Press the **DOWN** button to highlight Door Ajar Timeout.
- 6 Press the **INC** or **DEC** buttons to change the setting.
- 7 Press the **BACK** button to return to the Edit Configuration screen, or press the **HOME** button to exit. The new settings are saved.

8.8.7 Power Failure Alarm

The Power Failure Timeout specifies longest time the freezer can be without AC power before the alarm activates. If the time elapsed since the last power failure is greater than or equal to this value, the alarm activates.

- ▶ Default delay setting is three minutes
- ▶ Setting can be changed from 0 minutes to 60 minutes

Change the alarm delay:

- 1 Press the **MAIN** button.
- 2 Press the **DOWN** button to highlight Edit Configuration. Press the **SELECT** button.
- 3 Enter the password when prompted.
- 4 Press the **DOWN** button to highlight Alarm Setpoints. Press the **SELECT** button.
- 5 Press the **DOWN** button to highlight Power Failure Timeout.
- 6 Press the **INC** or **DEC** buttons to change the setting.
- 7 Press the **BACK** button to return to the Edit Configuration screen, or press the **HOME** button to exit. The new settings are saved.

8.8.8 Chart Paper Alarm

The default setting for the chart paper timer is Enabled. One sheet of chart paper records temperatures continuously for seven days. The timer activates an alarm 6.5 days from when the timer is reset. The timer period cannot be changed.

NOTE

- ▶ Available options are Enabled, Disabled, and Reset.
 - ▶ Enabling the timer also resets the timer.
-

Change the setting:

- 1 Press the **MAIN** button.
- 2 Press the **DOWN** button to highlight Edit Configuration. Press the **SELECT** button.
- 3 Enter the password when prompted.
- 4 Press the **DOWN** button to highlight System Options. Press the **SELECT** button.
- 5 Press the **DOWN** button to highlight Chart Paper Timer.
- 6 Press the **INC** or **DEC** buttons to select Enabled, Disabled, or Reset.
- 7 Do one of the following:
 - ▶ If Enabled or Disabled is selected, press the **BACK** button to return to the System Options screen, or press the **HOME** button to exit. The new setting is saved.
 - ▶ If Reset is selected:
 - a Press the **DOWN** button.
 - b Press the **PAPER-CHANGED** button. The System Options screen appears with the Chart Paper Timer set to Enabled.
- 8 Press the **BACK** button to return to the System Options screen, or press the **HOME** button to exit. The new setting is saved.

8.9 Test Alarms

Test alarms to ensure they are working correctly. The freezer has alarms for chamber temperature, compressor temperature, door open (time), no battery, and power failure.



NOTICE Before testing alarms, protect items in the freezer from extended exposure to adverse temperature.

8.9.1 Automatic Chamber Temperature Alarm Test

NOTE

- ▶ Calibrate the chamber temperature probe prior to performing the Automatic Chamber alarm test.
- ▶ The test can be aborted by selecting the Cancel High Test option.
- ▶ The test takes less than five minutes.

When performing an automatic temperature alarm test, the Peltier device heats the temperature probe until the high alarm setpoint is reached. An event is added to the Event Log to indicate a temperature alarm was activated.

Test the high alarm:

- 1 Identify the current setting for the high alarm setpoint.
- 2 Press the **MAIN** button.
- 3 Press the **DOWN** button to select System Alarm Test & Status. Press the **SELECT** button.
 - ▶ The System Alarm Test & Status screen appears.
- 4 Press the **DOWN** button to select Start High Alarm Auto Test. Press the **SELECT** button.
 - ▶ The “High Alarm Test in Progress” message appears. When the test is complete, the message clears.
- 5 View the Event Log. Note the temperature at which the high alarm occurred. Compare the temperature to the high alarm setpoint. If the values do not match, refer to chapter 11 (Troubleshooting).

Cancel the test:

- 1 Press the **MAIN** button.
- 2 Press the **DOWN** button to select System Alarm Test & Status. Press the **SELECT** button.
 - ▶ The System Alarm Test & Status screen appears.
- 3 Press the **DOWN** button to select Cancel High Test. Press the **ENTER** button.
 - ▶ The test is cancelled.

NOTE When cancelling an automatic test, the message indicating the test is in progress clears immediately. If a setpoint was reached before the test was cancelled, the alarm activates and clears, as described earlier.

8.9.2 Manual Chamber Alarm Test



NOTICE Before testing alarms, protect items in freezer from extended exposure to adverse temperature.

Obtain:

- ▶ Independent thermometer, calibrated and traceable per national standards
- ▶ (1) 4 oz. (120 mL) glass of product simulation solution (1:1 ratio of water to propylene glycol or equivalent low-temperature fluid).



NOTICE Temperature probes are fragile; handle with care.

Test the high alarm:

- 1 Identify setting for high alarm setpoint.
- 2 Immerse the independent thermometer in the glass of product simulation solution.
- 3 Place the glass in the freezer and close the door.
- 4 When the glass contents have stabilized at the chamber temperature, remove the glass from the freezer.
- 5 While stirring probe in product simulation solution, allow the glass contents to warm up to room temperature and observe the temperature on the monitor.
- 6 When high temperature alarm is activated, note the temperature on the independent thermometer.
- 7 Remove the probe from the glass.
- 8 Place probe in probe bottle, immersing it at least 2" (50mm).
- 9 Compare the temperature at which the alarm is activated to the high alarm setpoint. If values do not match, calibrate the temperature probe.

8.9.3 Power Failure Alarm Test

NOTE

- ▶ During a power failure, the power failure alarm activates and the batteries provide power to the monitoring system.
- ▶ If AC power fails, the backup batteries will allow for continued data collection and temperature display.
- ▶ If the backup batteries fail, data is not collected and the temperature is not displayed.
- ▶ When power is restored, the 24 hours of data prior to the power loss are retained in the system memory. Stored temperature data is displayed on the graph and the monitoring system resumes data collection and display.

- 1 Confirm the freezer is connected to AC power.
- 2 Ensure the monitoring system backup batteries are installed.
- 3 Change Power Failure Timeout setting to 0 minutes.
 - a Press the **MAIN** button.
 - b Press the **DOWN** button to highlight Edit Configuration. Press the **SELECT** button.
 - c Enter the password when prompted.
 - d Press the **DOWN** button to highlight Alarm Setpoints. Press the **SELECT** button.
 - e Press the **DOWN** button to highlight Power Failure Timeout.
 - f Press the **DEC** button to change the setting to 0.
- 4 Switch the AC ON/OFF switch **OFF**. Power failure alarm will activate immediately.
- 5 Switch the AC ON/OFF switch **ON**. Power failure alarm will clear and audible alarm will cease.
- 6 Change the Power Failure Timeout setting to the original setting.

8.9.4 Door Ajar Alarm Test

- 1 Change Door Ajar Timeout setting to 0 minutes:
 - a Press the **MAIN** button.
 - b Press the **DOWN** button to highlight Edit Configuration. Press the **SELECT** button.
 - c Enter the password when prompted.
 - d Press the **DOWN** button to highlight Agitator Setpoints. Press the **SELECT** button.
 - e Press the **DOWN** button to highlight Door Ajar Timeout.
 - f Press the **DEC** button to change the setting to 0.
 - g Press the **BACK** button to return to the Edit Configuration screen, or press the **HOME** button to exit. New settings are saved.
- 2 Open the door. Door ajar alarm will activate immediately.
- 3 Close the door. Door ajar alarm will clear and audible alarm will cease.
- 4 Change the Door Ajar Timeout setting to the original setting.

8.9.5 No Battery Alarm Test

Test the no battery alarm to ensure the batteries can provide enough power to the monitoring system and power failure alarm in the event of a power failure.

-
- NOTE**
- ▶ During an AC power failure, the power failure alarm is activated and the batteries provide power to the monitoring system.
 - ▶ If AC power fails, the backup batteries will allow for continued data collection and temperature display.
 - ▶ If the backup batteries fail, data is not collected and the temperature is not displayed.
-

Test the alarm:

- 1 Ensure the monitoring system backup batteries are installed.
- 2 Remove one battery from the monitoring system backup battery holder.
 - a If the no battery alarm activates, no further action is needed. Reinstall the battery.
 - b If the no battery alarm does not activate, contact Helmer Technical Service.



-
- NOTICE** When installing replacement batteries, use only batteries which meets the specifications outlined in chapter **10.7** (Supplies).
-

8.10 Additional System Settings

8.10.1 Screen Contrast

The screen contrast can be changed for easier viewing.

-
- NOTE**
- ▶ During an AC power failure, the screen backlight is not illuminated to conserve backup battery power.
 - ▶ During an AC power failure, the screen contrast cannot be changed..
-

Change screen contrast:

- 1 On the HOME screen, press the third button from the left to make the text appear lighter.
- 2 On the HOME screen, press the second button from the left to make the text appear darker.

8.10.2 Date and Time

The Date Format setting controls the order in which the month (mm) and day (dd) are displayed.

- ▶ Month is a 2-digit number (01-12)
- ▶ Day is a 2-digit number (01-31)
- ▶ Default date format is mm/dd/yyyy

The Clock Mode setting controls whether the time is displayed in a 12-hour or 24-hour format.

- ▶ When using the 12-hour format, AM or PM must be specified
- ▶ Default setting is 12-hour

Change date and time settings:

- 1 Press the **MAIN** button.
- 2 Press the **DOWN** button to highlight Edit Configuration. Press the **SELECT** button.
- 3 Enter the password when prompted.
- 4 Press the **DOWN** button to highlight Set Date & Time. Press the **SELECT** button.
- 5 Press the **UP** or **DOWN** buttons to select the date and time settings to change.
- 6 Press the **INC** or **DEC** buttons to change the setting.
- 7 Press the **BACK** button to return to the Edit Configuration screen, or press the **HOME** button to exit.
The new settings are saved.

8.10.3 Display Language

The i.Center monitoring system stores two languages. English is the default language. If a different language is desired, it must be loaded from the flash memory card. If a flash memory card is not included with the freezer, the languages may have been loaded to the i.Center monitoring system prior to shipment.

To obtain a flash memory card to load an alternate language, contact Helmer Technical Service.

NOTE Each time the freezer is powered on, the i.Center display language must be selected.

Set the display language on power-on:

- 1 Switch the AC ON/OFF switch **ON**.
- 2 Install the monitoring system battery that is taped next to the backup battery holder.
 - ▶ The freezer powers on and the i.Center monitoring system will display the System Options screen.
- 3 Press the **INC** or **DEC** buttons to select the desired language. Press the **SELECT** button.
- 4 Press the **HOME** button to return to the HOME screen.
- 5 If a temperature alarm sounds, press the **MUTE** button.

Change the display language:

- 1 Press the **MAIN** button.
- 2 Press the **DOWN** button to highlight Edit Configuration. Press the **SELECT** button.
- 3 Enter the password when prompted.
- 4 Press the **DOWN** button to highlight System Options. Press the **SELECT** button.
- 5 Press the **UP** or **DOWN** buttons to select Language. Press the **SELECT** button.
- 6 Press the **INC** or **DEC** buttons to select the desired language.
- 7 Press the **BACK** button to return to the System Options screen, or press the **HOME** button to exit.
The new settings are saved.

8.10.4 Temperature Units

Available options are Celsius (°C) or Fahrenheit (°F). The default temperature unit is Celsius.

Change temperature units:

- 1 Press the **MAIN** button.
- 2 Press the **DOWN** button to highlight Edit Configuration. Press the **SELECT** button.
- 3 Enter the password when prompted.
- 4 Press the **DOWN** button to highlight System Options. Press the **SELECT** button.
- 5 Press the **DOWN** button to highlight Temperature Units.
- 6 Press the **INC** or **DEC** buttons to select the desired temperature units.
- 7 Press the **BACK** button to return to the Edit Configuration screen, or press the **HOME** button to exit. The new setting is saved.

8.11 Event Log

The Event Log shows information from alarm events.

- ▶ 50 (most recent) events can be viewed on the Event Log screen.
- ▶ Number of door openings for the current and previous day can be viewed.

View the event log:


- 1 Press the **MAIN** button.
 - ▶ Event Log is highlighted.
- 2 Press the **SELECT** button.
 - ▶ The Event Log screen is displayed.

Event log format:

```
EVENT LOG Door AA/AA BB/BB
              Openings: C D
EE F GG HH/HH/HH II:IJ KK.KK°L
```

Item	Description
AA/AA	Current date (month and day)
BB/BB	Previous date (month and day)
C	Number of door openings on current date
D	Number of door openings on previous date
EE	Event number. The most recent event is numbered as 1. Values can be 1-50.
F	Event. "S" indicates the start of an alarm condition. "R" indicates the alarm was reset and the system returned to normal.
GG	Alarm Type: DR Door Open HI High temperature CO Condenser temperature NB No Battery AC Power failure
HH/HH/HH	Date of event (month and day, and the last two digits of the year)
II:II	Time (hours and minutes) of event
J	Time (appears for 12-hour format). "A" indicates AM. "P" indicates PM.
KK.KK	Chamber temperature at time of event
L	Temperature units. C = Celsius. F = Fahrenheit.

8.11.1 Event Details



Event Log Detail screen.

Label	Description
A	Event number
B	Event
C	Alarm Type
D	Date and time of event
E	Chamber temperature at time of event
F	Condenser temperature at time of event

View an event:

- 1 Press the **MAIN** button.
 - ▶ Event Log is highlighted.
- 2 Press the **SELECT** button.
 - ▶ The Event Log screen is displayed.
- 3 From the Event Log screen, press the **UP** or **DOWN** buttons to highlight the desired event number. Press the **SELECT** button.
 - ▶ The Event Log Detail screen for the selected event is displayed.
- 4 Press the **BACK** button to return to the Event Log screen, or press the **HOME** button to exit.

NOTE If the event is highlighted the alarm for that event was caused by a system self-test, initiated by an operator.

8.12 Defrost Log

The DEFROST LOG screen displays information about the previous 50 defrost events.

View a defrost event:

- 1 Press the **MAIN** button.
 - ▶ Event Log is highlighted.
- 2 Press the **SELECT** button.
 - ▶ The Event Log screen is displayed.
- 3 Press the **DOWN** button to highlight Defrost Log. Press the **SELECT** button.
 - ▶ The Defrost Log Detail screen is displayed.


The following is the format for the defrost log:

AA B CC/CC/CCCC DD:DD E FF.FF°G H

Item	Description
AA	Defrost event number. The most recent event is numbered as 1. Values can be 1-50.
B	Defrost event. S indicates the start of the defrost event. E indicates the end of the defrost event.
CC/CC/CCCC	Date of event
DD:DD	Time (hours and minutes) of event
E	Time (12 Hour format only). A indicates AM, and P indicates PM.
FF.FF	Highest upper chamber temperature recorded since the previous event
G	Temperature measurement system. C indicates Celsius, F indicates Fahrenheit.
H	Number of door openings since the previous event.

View defrost event details:

- From the Defrost Log screen, press the **UP** or **DOWN** arrow buttons until the desired defrost event is displayed. Press the **SELECT** button.
 - The Defrost Log Detail screen for the selected event is displayed.



Defrost Log Detail screen.

Label	Description
A	Event number
B	Event type
C	Date and time of event
D	Number of door openings during the event
E	Highest upper chamber temperature recorded during the event
F	Highest lower chamber temperature recorded during the event
G	Highest condenser discharge line temperature recorded during the event

8.13 Upgrade System Firmware

Helmer may occasionally issue updates for the i.Center firmware. Follow upgrade instructions included with the firmware update.

8.14 Reset the i.Center Monitoring System

- 1 Remove one battery from the monitoring system backup battery holder.
- 2 Switch the AC ON/OFF switch **OFF**.
- 3 Switch the AC ON/OFF switch **ON**.
- 4 Reinstall the battery in the monitoring system backup battery holder.

8.15 View Manufacturer and Product Information

- 1 Press the **MAIN** button.
- 2 Press the **INC** or **DEC** buttons to select the Product/Company Information option. Press the **SELECT** button.
 - ▶ Manufacturer contact information appears.
 - ▶ Software version appears.

9 Temperature Controller Setpoints



Independent temperature controller.

Temperature controller setpoints are programmed at the factory. Setpoints can be viewed and changed through the temperature controller.

9.1 Change the Freezer Setpoint

- NOTE**
- ▶ Default setpoint is -32.0 °C (which causes the freezer to maintain a temperature of -30 °C).
 - ▶ When there is no interaction for four minutes, the temperature controller exits program mode and returns to normal mode.
 - ▶ The reference temperature displayed on the temperature controller may not be the same as the temperature displayed on the i.Center monitoring system.

- 1 Observe the chamber temperature displayed on the i.Center monitoring system.
- 2 Determine how much the freezer setpoint will be changed.

- EXAMPLE**
- ▶ Current setpoint is -30.0 °C
 - ▶ Target setpoint is -28.0 °C
 - ▶ Setpoint adjustment value is +2.0 °C

- 3 On the temperature controller, press and hold the **P** button.
 - ▶ “PXX” is displayed, where “XX” is a parameter number.

- 4 Adjust the freezer setpoint.
 - a Press the **UP** or **DOWN** arrow buttons until “P03” is displayed.
 - b Press the **P** button.
 - ▶ The current setpoint is displayed.
 - c Press the **UP** or **DOWN** arrow buttons to change the temperature setpoint by the same value as determined in step 2.
 - d Press the **P** button.
 - ▶ The setpoint is changed and “P03” is displayed.
- 6 Exit program mode:
 - a Press the **UP** or **DOWN** arrow buttons until “P01” is displayed, or
 - b Do not press any buttons for four minutes. Parameter 01 (“P01”) is displayed.

9.2

Change the Control Sensor Offset

The temperature controller senses chamber temperature through a probe in the unit cooler. The chamber setpoint typically varies from the measured temperature, so an offset value is used by the control system to compensate for the difference.

- ▶ Value is factory-preset and varies for each unit
- ▶ Offset value can be changed from -10.0 °C to +10.0 °C



NOTICE Control sensor offset is factory-preset and should not be changed unless directed by Helmer Technical Service.

NOTE If the variance is within acceptable limits for your organization, changing the offset value is optional.

9.3

Change the Hysteresis Value

- ▶ Default setpoint is 4.0 °C
- ▶ Allowable temperature variance above the freezer setpoint



NOTICE Hysteresis is factory-preset and should not be changed unless directed by Helmer Technical Service.

10 Maintenance



- NOTICE**
- ▶ Before performing maintenance, protect items in freezer from extended exposure to adverse temperature.
 - ▶ Allow freezer temperature to stabilize at setpoint after performing service or after extended door opening.

NOTE Refer to the operation manual for the preventive maintenance schedule.

10.1 Recharge Refrigerant



- CAUTION**
- ▶ Review all safety instructions prior to recharging refrigerant. Refer to chapter 2 (Safety).
 - ▶ Maintenance should only be performed by trained refrigeration technicians.



NOTICE Use only non-CFC R-404A refrigerant.

Full initial refrigerant charge varies by model and power requirements, which can be found on the product specification label.

Model	Initial Charge
105	11.0 oz. (312 g)

Obtain:

- ▶ Refrigerant
- ▶ Calibrated pressure gauge (0 psi to 220 psi (0 kPa to 1520 kPa))

Add refrigerant:

- 1 Attach pressure gauge to the fittings on the refrigeration lines.
- 2 Monitor the low side (suction) pressure through a full compressor cycle.
- 3 Measure the pressure at the end of the next cycle, immediately before the compressor stops.

NOTE Pressure varies depending on ambient air temperature.

- 4 Add refrigerant. Check the pressure on the low side and high side.
 - ▶ Low side = 4 psi to 7 psi (30 kPa to 50 kPa)
 - ▶ High side = 180 psi to 220 psi (690 kPa to 1520 kPa)
- 5 Remove pressure gauge.

10.2 Test Monitoring System Backup Batteries

The i.Center monitoring system has visual indicators for battery charge level. If the batteries deplete to a particular voltage output, a flashing Low Battery alarm is initiated. If the batteries are missing or nearly depleted, the flashing No Battery alarm initiates.

Test backup batteries:

- 1 Switch AC ON/OFF switch **OFF**.
 - ▶ Screen should continue to display information without backlight.
 - ▶ If the display is blank, replace battery.
- 2 Switch AC ON/OFF switch **ON**.

- 10.3 Replace Monitoring System Backup Batteries**
- 1 Open the access panel on the lower front of the freezer.
 - 2 Remove six batteries and replace with six new batteries.



NOTICE When installing replacement batteries, use only batteries which meets the specifications outlined in chapter **10.7** (Supplies).

- 3 Close the access panel.

10.4 Clean the Freezer

10.4.1 Condenser Grill

In environments where freezer is exposed to excessive lint or dust, condenser grill may require cleaning more frequently than stated in preventive maintenance schedule.

Clean the condenser grill using a soft brush and a vacuum cleaner.

10.4.2 Exterior

Clean exterior surfaces with soft cotton cloth and non-abrasive liquid cleaner.

10.4.3 Interior

Clean painted surfaces with mild detergent. Clean stainless steel surfaces with a general-purpose laboratory cleaner suitable for stainless steel.

10.4.4 Door Gaskets

Clean with soft cloth and mild soap and water solution.

10.4.5 Clean and Refill Probe Bottle

NOTE A kit that includes a probe bottle and propylene glycol is available from Helmer.

Obtain:

- ▶ Fresh water-bleach solution (not provided)
 - ▶ 1:9 ratio of bleach to water
 - ▶ Bleach is 5% solution of commercial sodium hypochlorite (NaOCl)
 - ▶ Equivalent oxidizing cleaner/disinfectant approved by your organization may be substituted
- ▶ 4 oz. (120 mL) of product simulation solution per bottle
 - ▶ 1:1 ratio of water to propylene glycol (or equivalent low-temperature fluid)

Clean and refill bottle:

- 1 Remove probe from bottle.
- 2 Remove bottle from bracket.
- 3 Clean bottle with water-bleach solution.
- 4 Fill bottle with 4 oz. (120 mL) of product simulation solution.
- 5 Cap bottle tightly to minimize evaporation.
- 6 Place bottle in bracket.
- 7 Replace probe, immersing at least 2" (50 mm).

10.5 Defrost the Unit Cooler

Defrost cycles are programmed to occur at specific times. A defrost cycle can be manually initiated, outside of the programmed defrost times, as described below.



Independent temperature controller (defrost lamp circled).

Start a defrost event:


- 1 Ensure the temperature controller is in programming mode,
 - a Press the **UP** or **DOWN** arrow buttons until “P01” is displayed, or
 - b Do not press any buttons for four minutes. Parameter 01 (“P01”) is displayed.
- 2 Press and hold the UP arrow button for about two seconds.
 - ▶ The defrost lamp illuminates.
 - ▶ The defrost icon on the i.Center monitoring system is displayed.
 - ▶ The defrost event is started.

10.6 Unit Cooler Cover Removal and Installation

If unit cooler cover is not removed as detailed in this procedure the drain port may be damaged. Improper drainage may result in excessive icing and freezer’s inability to maintain temperature.

Required tools:

- ▶ 5/16” socket wrench
- ▶ #2 Phillips screwdriver
- ▶ Tool to push putty away from the drain hose



Drain line, fan, and heater components.

Label	Description
A	Unit cooler cover
B	Drain port
C	Drain fan
D	Fan tube
E	Heating element
F	Heater wires
G	Protective cover
H	Drain tube

10.6.1 Remove the Unit Cooler Cover



CAUTION Disconnect the freezer from AC power when removing the unit cooler.

- 1 Switch AC ON/OFF switch **OFF**. Remove one battery from the monitoring system backup battery holder.
- 2 Remove the rear protective cover (G) on the rear of the cabinet.
 - a Using a #2 Phillips screwdriver, loosen four screws securing the cover to the cabinet.
 - b Slide the cover up and remove it from the cabinet.
 - c Cut the wire ties securing the drain line to the cabinet.
- 3 On the back of the cabinet, peel the putty back to expose the drain tube (H) and drain heater (E).



CAUTION The condensate evaporator and water evaporation tray are hot.

- 4 Inside the cabinet, remove the putty around the drain tube.
- 5 Remove the wire ties securing the heater wires (F) to the cabinet. Verify the heating element is cool.
- 6 Remove the drain heater from the drain tube.
- 7 Remove the drain tube (H) by pulling it downward. The drain tube should separate from the fan tube (D) at the 90° elbow, leaving the fan tube (D) attached to the fan (C).
 - a The section of the drain tube inside the cabinet should separate from unit cooler drain port (B).
 - b Gently twist the drain tube from left to right to separate it from the unit cooler drain port.
 - c Pivot the drain tube upward then remove it from the cabinet.
- 8 Remove top drawer, basket, or shelf from the chamber.
- 9 Remove the unit cooler cover (A).
 - a Hold unit cooler cover in place to prevent it from dropping.
 - b Use the socket wrench to remove four screws securing the unit cooler cover.
 - c Carefully lower unit cooler cover to avoid damage to the fan wiring.

10.6.2 Install the Unit Cooler Cover

- 1 Verify unit cooler wiring is connected and routed correctly.
 - a Wiring should be routed above copper tube inside the unit cooler.
 - b Reconnect wires if they have separated.
- 2 Attach unit cooler cover.
 - a Lift unit cooler cover into place.
 - b Front edge of the cover should be behind the unit cooler case.
 - c Use the socket wrench to install four screws to secure the unit cooler cover.

- 3 Insert the drain tube through hole in the cabinet.
 - a Push drain tube upward at an angle, toward the unit cooler drain port.
 - b Picot the drain tube downward then push the tube upward.
 - c In the chamber, push the drain tube onto unit cooler drain port.
- 4 Attach the drain tube to the fan tube.
- 5 Insert the drain line heater in the drain tube.
 - a Insert the heater at an upward angle.
 - b The black heating element should no longer be visible.
- 6 Reinstall top drawer, basket, or shelf if previously removed.
- 7 Reattach the drain line heater wires to the cabinet.
- 8 On the back of the cabinet, press putty around the drain hose and partially into the hole.
- 9 Install the protective cover on the rear of the cabinet.
- 10 Switch AC ON/OFF switch **ON**. Reinstall the battery in the monitoring system backup battery holder.
- 11 Press the **MUTE** button to disable the high temperature alarm while freezer reaches operating temperature.

10.7 Supplies

Refrigerant: non-CFC, R-404A
 Chart paper: 220419 (52 sheets)
 Propylene glycol solution: 400922-2
 Monitoring system backup batteries: (6) 1.5 V D-cell, non-rechargeable alkaline (or equivalent)
 Chart recorder backup battery (optional): (1) 9 V non-rechargeable alkaline (or equivalent)

11 Troubleshooting



CAUTION ▶ Review all safety instructions prior to troubleshooting. Refer to chapter 2 (Safety).
 ▶ Troubleshooting should only be performed by trained refrigeration technicians.

11.1 General Operation Problems

Problem	Possible Cause	Action
A drawer does not slide easily.	A drawer slide is faulty.	▶ Confirm the slide is operating correctly. Replace if necessary.
	Debris in the drawer slides.	▶ Pull the drawer out and confirm the slides are free of debris. Clean if necessary.
	Ice buildup in the drawer slides.	▶ Pull the drawer out and confirm the slides are free of ice. De-ice and clean if necessary.
	Drawer slides are not lubricated.	▶ Using a lightweight oil, lubricate the bearings in the slides.
	Drawer is misaligned or not level.	▶ Confirm both slides for the drawer are mounted at the same height.
Door does not open easily.	Debris in the hinges.	▶ Confirm the hinges are free of debris. Clean the hinges if necessary.
	Door hinges are not lubricated.	▶ Using a general-purpose grease, lubricate the pivots in the hinges.
	Lower hinge spring and/or pin may be bent or faulty.	▶ Confirm the hinge spring and pin assembly is not damaged. Replace entire hinge if necessary.

Problem	Possible Cause	Action
Display on the temperature/defrost controller is flashing.	Defrost probe or temperature probe wiring is an open circuit; or a component is faulty or internal connections are loose.	<ul style="list-style-type: none"> ▶ Check the continuity of the probe wiring and connections. Secure the connections if necessary. ▶ Confirm the probe is providing resistance in the range of 1191 Ω to 2000 Ω. Replace the probe if necessary.
Monitor display is hard to read.	Screen contrast is set too low.	▶ Change the screen contrast.
Alarm monitor is not responding.	Digital electronics are locked because of an interruption in power.	▶ Reset the monitoring system.

11.2

Chamber Temperature Problems

Problem	Possible Cause	Action
Chamber temperature displayed is higher or lower than the actual temperature.	Connections for the chamber temperature probe are loose.	▶ Test the probe connections. Secure the connections if necessary.
	Temperature probe wiring is an open circuit.	▶ Check the continuity of the probe wiring. Replace the probe if necessary.
	Probe bottle is empty, or the amount of solution is too low.	▶ Check the level of product simulation solution in the bottle. Clean/refill the bottle if necessary.
	Monitor is not calibrated.	▶ Confirm the temperature probe is reading correctly. Calibrate the chamber probe if necessary.
	Solution in the probe bottle is frozen.	▶ Refill the bottle with new solution.
	Digital electronics are locked because of an interruption in power.	▶ Reset the monitoring system.
An error code displays on the monitor.	A component is faulty or internal connections are loose.	▶ Contact a qualified service technician.
Chamber temperature meets an alarm condition, but the appropriate temperature alarm is not active.	Temperature alarm setpoint was changed.	▶ Check the current setpoints for the temperature alarms. Change the setpoints if necessary.

Problem	Possible Cause	Action
Chamber temperature does not stabilize at the freezer setpoint.	Condenser grill is dirty.	▶ Check the condenser grill. Clean it if necessary.
	Circulation in the chamber is not adequate.	▶ Check if there are any items obstructing air flow and remove them if necessary.
	Ambient air temperature around the freezer is too high.	▶ Confirm the freezer is placed appropriately.
	Refrigerant level is too low.	▶ Check the refrigerant level. Recharge the refrigerant if necessary.
	A component is faulty or internal connections are loose.	▶ Contact a qualified service technician.
	Compressor starting relay is faulty.	▶ Confirm the relay is operating correctly. Replace the relay if necessary.
	Defrost controller is faulty.	▶ Confirm monitor/control board or temperature/defrost controller is operating correctly. Replace the board or controller if necessary.
	Compressor fan is not running.	▶ Check the compressor fan connections. Replace the fan motor if necessary.
	Unit cooler fan is not running.	▶ Activate the door switch, wait for the fan delay to elapse (about 15 to 30 seconds), then check the voltage to the fan. Replace the fan motor or door switch if necessary.
	Compressor motor has seized.	▶ Replace the compressor.
	Temperature control probe is faulty.	▶ Confirm the probe is providing resistance in the range of 1191 Ω to 2000 Ω . Replace the probe if necessary.

11.3 Alarm Activation Problems

Problem	Possible Cause	Action
Freezer is in an alarm condition, but alarms are not audible.	A component is faulty or internal connections are loose.	▶ Confirm the circuit board and line connections are functioning correctly.
	Control board is faulty.	▶ Replace parts with those included in the control and display board kit.
	Alarm buzzer is faulty.	▶ Replace the alarm buzzer.
	Audible alarms have been muted.	▶ Verify audible alarms are not muted. If the time remaining on the MUTE timer is greater than five minutes, change the MUTE timer value to five minutes and wait until timer resets.
No Battery alarm is activating sporadically.	Battery voltage level on the backup batteries for the monitoring system is low.	▶ Replace the backup batteries for the monitoring system.

Problem	Possible Cause	Action
An alarm activated, but the temperature recorded at activation does not match the alarm setpoint.	Monitor settings are not calibrated.	▶ Confirm temperature probe is reading correctly. Calibrate if necessary.
	Temperature changed slightly around the time of activation.	▶ No action needed.
Freezer is connected to outlet power, but the Power Failure alarm is active.	Outlet connection is faulty.	▶ Verify power at the outlet. Repair the outlet or connect to a different outlet.
	Power cord is faulty.	▶ Confirm the cord is connected securely. Secure cord if necessary.
	Power supply board is faulty.	▶ Replace the power supply board.
	Lower front panel AC power switch is OFF.	▶ Turn AC power switch ON.
	A component is faulty or internal connections are loose.	▶ Contact a qualified service technician.
Door Open alarm is activating sporadically.	Door is not closing completely.	▶ Confirm the lower hinge and/or spring is not damaged. Check/change tension. Replace if necessary. ▶ Confirm door is aligned.
	Door is closing but not sealing completely.	▶ Confirm the door gasket seals completely. Replace the door gasket if necessary.
	Connections for the door switch are faulty.	▶ Test the switch connections. Secure the connections if necessary.
	Door switch is faulty.	▶ Replace the door switch.
	Control board is faulty.	▶ Replace parts with those included in the control and display board kit.
	Door Ajar Timeout is set to zero, causing the alarm to activate immediately when the door is opened.	▶ Check the current setpoint for the Door Ajar alarm. Change the setpoint if necessary.
All alarms are activating sporadically.	Alarm system is faulty.	▶ Confirm the circuit board and line connections are functioning correctly.
	Control board is faulty.	▶ Replace parts with those included in the control and display board kit.
	A component is faulty or internal connections are loose.	▶ Contact a qualified service technician.

Problem	Possible Cause	Action
Condenser alarm is active.	Refrigerant level is too low.	▶ Check level. Recharge if needed.
	Condenser temperature probe connections are loose.	▶ Test connections. Secure if needed.
	Condenser temperature probe is faulty.	▶ Test the probe. Replace if necessary.
	Condensing unit fan motor is faulty.	▶ Replace unit fan motor.
	Condenser probe is not calibrated.	▶ Confirm condenser probe is reading correctly. Calibrate if necessary.
	Compressor is overheating due to lack of airflow.	▶ Check condenser grill, and clean if needed. ▶ Confirm freezer is placed appropriately.
	Condenser alarm setpoint is too low.	▶ Confirm the alarm setpoint is set at the appropriate value.
High Temperature alarm activates when the door is opened, then clears shortly after the door is closed.	Probe bottle is empty.	▶ Check the level of product simulation solution in the bottle. Refill the bottle if necessary.
	High temperature alarm setpoint is set too low.	▶ Check the setpoint. Change the setpoint if necessary.
	A component is faulty or internal connections are loose.	▶ Contact a qualified service technician.

11.4 Testing Problems

Problem	Possible Cause	Action
Automatic temperature tests do not work.	A component is faulty or connections for the chamber temperature probe are loose.	▶ Test the probe connections. Secure the connections if necessary.
	Chamber temperature probe is faulty.	▶ Test the probe. Replace the probe if necessary.
	Control board is faulty.	▶ Replace parts with those included in the control and display board kit.
	High Alarm setpoint is set significantly higher than the default value.	▶ Confirm the alarm setpoints are set at the appropriate values. ▶ Test the temperature alarms manually.

11.5 Condensation Problems

Problem	Possible Cause	Action
After defrosting, no water flows into the water evaporation tray.	Not enough time has elapsed since the end of the defrost cycle.	▶ Wait until approximately 20 minutes after the defrost cycle has ended.
	Drain line is plugged.	▶ Confirm the drain tube is free of debris. Remove debris if necessary.
	Drain line heater is not working.	<ul style="list-style-type: none"> ▶ Confirm the connections are secure. Tighten the connections if necessary. ▶ Confirm the drain line heater is warm to the touch. ▶ Replace the heater if necessary.
	Defrost heater on the evaporator in the unit cooler is not working.	<ul style="list-style-type: none"> ▶ After defrosting the freezer, monitor the evaporator for repeated ice buildup. ▶ Confirm the connections are secure. Tighten the connections if necessary. ▶ Confirm the defrost heater is hot and is drawing the appropriate current during a defrost event (approximately 3.9 A to 5.5 A). ▶ Replace the heater if necessary.
Excessive humidity on the door.	Humid air is entering the chamber.	▶ Confirm the freezer is level, and the doors are aligned, closing tightly, and sealing correctly. Contact a qualified service technician to correct issues as necessary.
	Relative humidity around the freezer is too high.	▶ Confirm the freezer is placed appropriately.
Excessive ice in the chamber.	Humid air is entering the chamber.	▶ Confirm the freezer is level, and the doors are aligned, closing tightly, and sealing correctly. Correct issues as necessary.
	Drain port on the unit cooler was damaged during removal of the unit cooler cover.	▶ Confirm the drain port on the unit cooler is intact.
	External fan is faulty.	<ul style="list-style-type: none"> ▶ Confirm the external drain fan is running. Hold a piece of paper in front of fan and check that the paper is being drawn toward the freezer. ▶ Confirm the connections are secure. Tighten the connections if necessary. ▶ Replace the external drain fan.

12 Parts




NOTICE

- ▶ Before replacing parts, protect items in freezer from extended exposure to adverse temperature.
- ▶ Allow freezer temperature to stabilize at setpoint after replacing parts or after extended door opening.

12.1 Front


12.1.1 Monitoring System



Monitoring features.

Label	Description	Part Number
A	i.Center stand-alone monitoring system (standard on iLF105)	Refer to section 12.1.2 for part numbers
B	Combined i.Center monitoring system and temperature chart recorder (standard on iPF105)	-
C	Chart paper	220419 (52 sheets)
Not shown	Chart recorder backup battery	120218

12.1.2 i.Center Display Parts



Left: Display assembly including LCD display and touchpad. Middle: Display board. Right: Control board.


Label	Description	Part Number	Schematic Label
A	LCD display (see note below)	120452	K
B	Touchpad	320722-1	K
C	Interface cable	400831-1	-
D	Display board	Included in the control and display board kit	K
E	Control board assembly (includes display and control board)	-	E
Not shown	Display assembly	400509-1 (includes LCD board and touchpad)	-



NOTICE The i.Center display assembly is sensitive to static electricity and can be damaged by electrostatic discharge. Use proper ESD precautions when handling the display assembly.

NOTE Although the LCD display and touchpad may be replaced individually, Helmer recommends replacing the entire display assembly.


12.1.3 Lower Panel



Front panel features.

Label	Description	Part Number	Schematic Label
A	Monitoring system backup batteries	715031	AE
B	Flash port	-	J15
C	Temperature controller	400540-2	B
D	Main power switch	120478	Q

12.2 Rear



Rear features.

Label	Description	Part Number	Schematic Label
A	Nut flanges for brace bars used in stacking undercounter units (four shown)	-	-
B	Rear access port	-	-
C	Drain line (copper tube segment)	400910-1	-
D	Product specification label	-	-
E	Power cord connector	120299	-
F	External drain fan		Z
G	Compressor/component rear compartment door	321184-1	-
H	Remote alarm contacts	-	-
I	i.Center monitoring system data port	-	-
J	RS-232 COM port (optional)	-	-
K	Power cord	-	-
L	Condenser probe	400674-1	AC
M	Compressor	Contact Helmer	A
N	Condensing unit fan motor	Contact Helmer	U
Not shown	Compressor solid state relay	400841-1	AD
	Caster (optional, swivel with brake)	220380	-

12.2.1 Electrical Tray

Kick plate (removed). Pull-out electrical components tray (open).



WARNING Disconnect the freezer from AC power before accessing the electrical tray.



NOTICE The control board is sensitive to static electricity and can be damaged by electrostatic discharge. Use proper ESD precautions when handling the board.

12.3


Interior



Interior features.

Label	Description	Part Number	Schematic Label
A	Door	Solid door Stainless steel: 400916-1 Powder coated: 400916-2	-
B	Drawer (plasma storage models)	400584-3	-
C	Door switch	120380	M
D	Roll-out basket (optional)	400890-3	-
E	Standard for shelf, drawer, or roll out basket	321173-1	-
F	Chamber temperature probe	400510-1	AB
G	Drawer slide for drawer or roll out basket	Left: 400541-6 Right: 400541-5	-
H	Probe bottle and propylene glycol kit	400922-2	-
I	Shelf (laboratory / pharmacy model)	400814-1	-


12.3.1 Unit Cooler



Left: Unit cooler with fan guard. Middle: Unit cooler fan. Right: Temperature control probe.

Label	Description	Part Number	Schematic Label
A	Unit cooler	-	-
B	Fan guard	-	-
C	Unit cooler fan	120540	H
D	Temperature control probe	120579	M

12.4 Door Hinges



Hinge, hinge spring and pin assembly, and door handle with key lock.

NOTE Spring tension is controlled at the point where the pin is stopped by the side plate (C, D).

Label	Description	Part Number
A	Hinge, covered, edge mount	220506
B	Hinge, uncovered, without spring assembly	-
C	Hinge, uncovered, spring and pin assembly	-
D	Close up, hinge spring and pin assembly	-
E	Door handle - Magnetic offset latch with key lock	220426
F	Door key lock with key, close-up	-

12.5 Side Access Panel


Undercounter freezers feature easy access for servicing, removal, and replacement of the compressor and condenser. The compressor is accessible from the rear and the side.



Side access panel.

13 Schematics

13.1 i.Series Schematic



14 **i.Center Screen Reference****HOME** screen**MAIN** button**MAIN** screen**MUTE** button (changes mute timer)**MAIN** screen**Event Log** option(Press the **SELECT** button)**EVENT LOG** screen**System Alarm Test & Status** option**SYSTEM ALARM TEST & STATUS** screen**Edit Configuration** option

(Enter the password)

CONFIGURATION screen**View Configuration** option**VIEW CONFIGURATION** screen**Product/Company Information** option**INFORMATION** screen**EVENT LOG** screen**EVENT LOG DETAIL** screen**DEFROST LOG** screen**EVENT LOG DETAIL** screen**SYSTEM ALARM TEST & STATUS** screen**Start High Alarm Auto Test** option**Cancel High Test** option**Chart Paper Days Left** or **Chart Paper Timer** display**Door Status** display**Condenser Temp** display**CONFIGURATION** screen**Set Date & Time** option**SET DATE & TIME** screen**System Options** option**SYSTEM OPTIONS** screen**Alarm Setpoints** option**SET ALARM SETPOINT** screen**Temperature Calibration** option**TEMPERATURE CALIBRATION** screen**Factory Default Settings** option**FACTORY DEFAULT SETTINGS** screen**Change Password** option

(Enter a new password)

SYSTEM OPTIONS screen

- Language option
- Date Format option
- Alarm Volume option
- Alarm Pulse option
- Temperature Units option
- Chart Paper Timer option

SET ALARM SETPOINT screen

- High Alarm Setpoint option
- Cond. Alarm Setpoint option
- Door Ajar Timeout option
- Power Failure Timeout option
- Temperature Graph option

TEMPERATURE CALIBRATION screen

- Temperature probe display
- Temperature option

VIEW CONFIGURATION screen

- Clock Mode display
- Date Format display
- Door Ajar Timeout display
- Pwr Failure Timeout display
- High Alarm Setpoint display
- Cond. Alarm Setpoint display
- Alarm Volume display
- Alarm Pulse display
- Chart Paper Days Left or Chart Paper Timer display
- Temperature Graph display

Section III: Horizon Series™ Models

15 Product Configuration

15.1 Install Battery for Backup Power

The monitoring system has a battery system, enabling a period of continuous operation if power is lost.

NOTE The monitoring system will start on battery power alone. If the freezer was previously not connected to AC power and the battery is connected, the monitoring system will begin running on battery power.

Battery life varies by manufacturer as well as voltage level remaining. Providing full power is available, and no battery-related alarms are active, backup power for the monitoring system is available for up to two hours.



NOTICE When installing a replacement battery, use only a battery which meets the specifications outlined in chapter 17.5 (Supplies).

The the battery is located below the chamber, behind the front cover.



Monitoring system backup battery.

Monitoring system battery is included in the accessory package. Install and connect the battery to provide monitoring system with backup power in the event of an AC power failure.

15.2 External Monitoring Devices



CAUTION

- ▶ The interface on the remote alarm monitoring system is intended for connection to the end user's central alarm system(s) that uses normally-open or normally-closed dry contacts.
- ▶ If an external power supply exceeding 30 V (RMS) or 60 V (DC) is connected to the remote alarm monitoring system's circuit, the remote alarm will not function properly; may be damaged; or may result in injury to the user.

NOTE In the event of a power failure, the power failure alarm condition is transmitted through the remote alarm contacts.

The remote alarm interface is a relay switch with three terminals:

- ▶ Common (COM)
- ▶ Normally Open (NO)
- ▶ Normally Closed (NC)

Terminals are dry contacts and do not supply voltage. Interface circuit is either normally open or normally closed, depending on terminals used. Requirements for your alarm system determine which alarm wires must connect to terminals.

- ▶ 0.5 A at 125 V (AC): 1 A at 250 V (DC)

15.2.1 Connect to Remote Alarm Interface

- 1 Switch AC ON/OFF switch **OFF**. Disconnect the monitoring system backup battery.
- 2 On the electrical box, locate the remote alarm terminals.
- 3 Connect remote alarm wires to appropriate terminals, according to requirements for your alarm system.
- 4 Use a cable tie to relieve strain on alarm wires (as necessary).
- 5 Switch AC ON/OFF switch **ON**. Reconnect the monitoring system backup battery.
- 6 Press the **MUTE** button to disable the high temperature alarm while freezer reaches operating temperature.

15.3 Schedule Defrost Events

Defrost events may be scheduled to occur at specific times.


Access to the defrost controller is available from the front of the freezer, in the pull-out components tray.



Kick plate (removed), and pull-out components tray (open).

Specify the number of defrost events to execute per day, as well as the time at which to initiate each defrost cycle. The cycles are based on the current time settings on the defrost controller.

The defrost controller features two time indicators and a time adjustment ring. The hour and minute hands show the current time in hours and minutes. The outer ring shows the current time including AM or PM, to the nearest 15-minute interval.



Defrost controller with current time set to approximately 9:30 AM.

Label	Description
A	PM indicator
B	Current time indicator (includes AM/PM, to the nearest 15-minute interval)
C	Current time indicator (hour and minutes only)
D	AM indicator
E	Time adjustment ring

15.3.1

Set Current Time

- 1 Switch the AC ON/OFF switch **OFF**. Turn the Alarm Disable key switch **OFF**.
- 2 Remove the kick plate and pull out the electrical tray.
- 3 Rotate the time adjustment ring clockwise until the current time indicators show the current time.
- 4 Push the electrical tray in and replace the kick plate.
- 5 Switch the AC ON/OFF switch **ON**. Turn the Alarm Disable key switch **ON**.
- 6 Press the **Mute** button to disable the high temperature alarm while freezer reaches operating temperature.

15.3.2

Set Defrost Time

- ▶ Default setting of three defrost events per day
- ▶ Default times are 12:00 AM, 8:00 AM, 4:00 PM
- ▶ Defrost events can be added or removed
- ▶ Defrost events can be scheduled for any time of day (in 15-minute intervals)
- ▶ Defrost cycle lasts 15 to 30 minutes
- ▶ Defrost events must be at least one hour apart



NOTICE Three defrost cycles are recommended for consistent freezer operation.

15.3.3

Schedule a Defrost Event

- ▶ Switch defrost event switch(es) to the **ON** position (outside) to initiate a defrost event at that time.
 - ▶ Switch defrost event switch(es) to the **OFF** position (inside) to cancel a defrost event at that time.
- 1 Switch the AC ON/OFF switch **OFF**. Turn the Alarm Disable key switch **OFF**.
 - 2 Remove the kick plate and pull out the electrical tray.

- 3 Add a defrost event:
 - ▶ At the appropriate time mark, position the switch **ON** (toward the outer ring).
- 4 Remove a defrost event:
 - ▶ At the appropriate time mark, position the switch **OFF** (toward the inside ring).
- 5 Push the electrical tray in and replace the kick plate.
- 6 Switch the AC ON/OFF switch **ON**. Turn the Alarm Disable key switch **ON**.
- 7 Press the **Mute** button to disable the high temperature alarm while freezer reaches operating temperature.



Defrost controller with defrost times set to On position at 12:00 AM, 8:00 AM, and 4:00 PM.

15.4 Move Drawers, Shelves, and Baskets



Storage features.



- CAUTION**
- ▶ Keep hands away from pinch points when closing the door.
 - ▶ Before moving drawers, ensure they are completely empty for safe lifting.
 - ▶ Maximum basket, drawer, or shelf load is 100 lbs (46 kg).



NOTICE Before moving storage components, protect stored items in freezer from extended exposure to adverse temperature.

Remove a drawer or basket:

- 1 Pull drawer or basket out until it stops.
- 2 Tilt the front of the drawer or basket upward.
- 3 Pull drawer or basket free of the slides.

Install a drawer or basket:

- 1 Tilt the front of the drawer or basket upward.
- 2 Set the wheels on the drawer or basket in the slides in the cabinet.
- 3 Lower the front of the drawer.
- 4 Gently push the drawer or basket into the chamber until it stops.
- 5 Pull drawer or basket out until it stops; check for smooth operation.

Remove a shelf:

- 1 With one hand, lift front edge of the shelf from the front brackets.
- 2 With the other hand, reach under the shelf and bump rear edge of the shelf upward to disengage rear brackets.

Install a shelf:

- 1 Insert shelf into chamber, placing it on brackets.
- 2 Gently bump rear edge of the shelf downward to engage brackets.
- 3 Pulling shelf forward gently; shelf should not disengage from rear brackets.

15.5**Move Slides and Brackets****Remove drawer slides:**

- 1 Using a screwdriver, remove front bracket retainers.
- 2 Tap front brackets upward to disengage standards.
- 3 Remove slides from standards.

Install drawer slides:

- 1 Insert slides into standard at appropriate height.
- 2 Tap front brackets downward to engage standards.
- 3 Using a screwdriver, install front bracket retainers.

Remove shelf brackets:

- 1 Using a screwdriver, remove front bracket retainers.
- 2 Tap front brackets upward to disengage standards.
- 3 Remove front brackets from standards.

Install shelf brackets:

- 1 Insert front brackets into standard at appropriate height.
- 2 Tap front brackets downward to engage standards.
- 3 Using a screwdriver, install front bracket retainers.

15.6**Level the Freezer****NOTE**

- ▶ Leveling feet are optional.
- ▶ Helmer recommends the use of leveling feet.
- ▶ A bubble level may be used to ensure the freezer is level.

Leveling feet must be adjusted to provide unit cooler drainage.

Front-to-back:

- 1 Rotate the leveling feet to raise or lower leveling feet.
- 2 When freezer is properly leveled, bottom of the unit cooler will slope downward from front to back (toward the condensate drain line).

Side-to-side:

- 1 Rotate the leveling feet to raise or lower leveling feet.
- 2 When freezer is properly leveled, bottom of the unit cooler will be horizontal (parallel to the floor).

15.7 Optional Adapter Kits for Medication Dispensing Locks

Contact Helmer Technical Service or your distributor for service documentation pertaining to medication dispensing locks.

15.8 Reverse Door Hinge and Handle



NOTICE Before reversing door hinge and handle, protect stored items in freezer from extended exposure to adverse temperature.

NOTE Freezer must be on the floor or on an elevated work surface with enough space in front of the freezer to lay the door face-down for disassembly.

15.8.1 Remove the Door and Hinges

- 1 Open the lower front control panel. Switch AC ON/OFF switch **OFF**. Disconnect the battery.
- 2 Remove four screws holding the kick panel on the cabinet. Set the kick panel aside.




- 3 Remove six screws holding the access panel and cover on the cabinet. Lay the panel in front of the cabinet, ensuring there is no strain on the power switch wires.



- 4 Remove plug from the access panel (on the handle-side of the freezer). Remove grommet from the hole (on the hinge-side of the freezer). Slide the data cable out of the slot (on the kick plate).



- 5 Cut the zip tie inside the cabinet.




- 6 Remove the door handle assembly.
 - a Remove four screws holding the door handle assembly on the door.
 - b Set the door handle assembly aside.



Door handle assembly.

- 7 Remove door latch / door catch.
 - a Remove two screws holding the door latch plates and spacer bar on the cabinet
 - b Set the latch plates and spacer bar aside.



Door latch plates.


- 8 With the door shut, remove the cover plate from both hinges.
- 9 Remove the spring assembly from the lower hinge.
 - a Use a J-hook tool to engage the left-most hole in the spring cap and rotate the spring cap from *left to right*, and hold.
 - b Remove the pin from the spring cap.
 - c Allow the spring to relax.
 - d Use a J-hook tool to engage any hole in the spring cap compress spring downward.
 - e Remove spring assembly from the lower hinge.
 - f Set the spring assembly aside.



NOTICE A second person should assist by supporting the door while the hinges are removed.

NOTE The two screws holding the hinge on the door are longer than the three screws holding the hinge on the cabinet. The screws must be installed in the same location when moving the hinge to the opposite side of the door.

- 10 Remove the lower hinge.
 - a Support the door.
 - b Remove five screws attaching the lower hinge to the door and cabinet.
 - c Remove the lower hinge.
 - d Reverse the hinge manually (as if moving the hinge from a fully-closed to a fully-open position).
 - e Set the lower hinge aside.
 - f Continue to support the door.
- 11 Remove the upper hinge.
 - a Remove five screws attaching the upper hinge to the door and cabinet.
 - b Remove the upper hinge.
 - c Reverse the hinge manually (as if moving the hinge from a fully-closed to a fully-open position).
 - d Set the upper hinge aside.




Hinge removal (lower hinge shown with spring removed).

- 12 Lay the door face-down in front of the cabinet. Ensure that there is no strain on the data cable passing from the cabinet to the door.

15.8.2 Reverse the Cable Routing in the Door

The undercounter door consists of an inner frame and outer frame. The data cable is connected to the display circuit board on the front of the door.

The length of the cable inside the door is approximately three feet. The cable follows a channel along the top and side of the outer frame. Additional slack has been bundled in the cable.




Outer door frame (right-hinged solid door shown) and data cable.

Label	Description
A	Outer door frame
B	Data cable (gray)
C	Cable exit (corner of door)
D	Additional cable slack


- 1 Lay the door assembly face-down on a solid work surface.
- 2 Remove remaining screws from both sides of the door assembly.
- 3 Lift the inner door frame out of the outer door frame and set aside. A J-hook tool may be used along the bottom edge of the door assembly to lift the inner frame.




- 4 Remove the plug from the handle-side of the door. Set the plug aside.



- 5 Pull the grommet out of the hole in the door. Slide the data cable out of the slot.



- 6 Re-route the data cable.
 - a Route the data cable inside the door and out through the slot in the corner opposite from where the cable had previously exited the door.
 - b Cable should follow the bottom edge of the door frame, as closely as possible.
 - c Tape the cable to the door frame.
 - d Excess slack in the cable should be outside of the door.



Left: Original cable routing (right-hinged door). Right: New cable routing (left-hinged door).


- 7 Route the data cable out of the door.
 - a Slide the data cable through the slot in the door.
 - b Insert the door-side grommet into the hole in the door.
- 8 Reinstall the inner door frame inside the outer door frame. Install screws in the unused holes on the door where hinges were originally installed.

15.8.3

Reinstall the Door and Hinges

- 1 Install the hinges and hinge plates on the door.
 - a Hand-thread two screws through each hinge and into the door.
 - b Leave the screws slightly loose.
 - c If a shim was used on the lower hinge, transfer the shim to the new hinge location.

NOTE Ensure that the upper and lower hinges are not interchanged when moving the hinges to the opposite side of the door.




Attach hinge to door (lower hinge shown).



NOTICE A second person should assist by supporting the door while the hinges are installed.

- 2 Install the door on the cabinet.
 - a Lift the door to the cabinet.
 - b Align the holes in the hinges with the corresponding holes in the cabinet.
 - c Hand-thread three screws through each hinge and into the cabinet.
 - d Do not allow the weight of the door to rest on the hinges.



Attach hinge to cabinet (lower hinge shown).

- 3 Align the door and tighten screws.
 - a Support the door so the top edge of the door is level.
 - b Level the door using a shim if necessary.
 - c Tighten all screws attaching both hinges to the door and to the cabinet.


NOTE If a shim is necessary to level the door after hinge reversal, contact Helmer Technical Service to obtain a shim.

- 4 Route the data cable across the front of the cabinet. Attach the cable to the zip tie holder under the cabinet on the hinge side.




Data cable secured at the hinge-side of the cabinet after hinge reversal.


- 5 Install the data cable in the door.
 - a Slide the data cable through the slot in the access panel.
 - b Install the grommet in the hole.
 - c Install the plug in the access panel on the opposite side.
 - d Allow enough slack (approximately 3") in the data cable between the door and the cabinet so the door can pivot open and closed without straining the cable.
- 6 Install the access panel and cover.
- 7 Install the kick panel.
- 8 Install the door handle on the opposite side of the door.
- 9 Install the latch plates and spacer bar on the opposite side of the cabinet.
- 10 Install the hinge spring and pin assembly.
 - a Close the door.
 - b Assemble the hinge spring assembly for the left side of the door (Figure A).
 - c Orient the bend in the coil toward the front of the freezer (Figure B).
 - d Slide the internal hex cap (with washer) on to the upper hex bolt in the lower hinge.



- e Use a J-hook tool in the spring cap to compress the spring upward (Figure C).
- f While compressing the spring, slide the spring cap over the lower hex bolt in the lower hinge (Figure D).



- g Use a J-hook tool to engage the right-most hole in the spring cap and rotate the spring cap from *right to left*, and hold.
- h Count four holes, starting from and including the spring cap hole closest to the end of the coil.
- i Insert the pin in the fourth hole.



Rotate the spring using a J-hook tool then insert pin (left-hinged door shown).

- 11 Switch AC ON/OFF switch **ON**. Reconnect the battery.
- 12 Close the lower front control panel.
- 13 Press the **MUTE** button to disable the high temperature alarm while freezer reaches operating temperature.
- 14 Verify the door is level and the hinges operate smoothly and the door seals tightly.

15.9

Stacked Undercounter Units



WARNING

- ▶ For a stacked configuration, both units must have leveling feet installed.
- ▶ The back brace bars and front stabilizing brackets must be installed.
- ▶ When stacking a refrigerator and freezer (104 and/or 105 models), place the heavier unit on the bottom.
- ▶ Do not open multiple, loaded drawers or baskets at the same time.

Call Helmer or your distributor for more information on the stacking kit, and for methods to secure both units to the wall and/or the floor.

16 Settings


Through the Horizon Series monitoring and control system, current settings may be viewed and changed.



NOTICE

- ▶ Control Sensor Offset and Hysteresis settings are factory-preset and should not be changed unless directed by Helmer Technical Service.
- ▶ Changing temperature settings affects operation of the freezer. Do not change settings unless instructed by Helmer Technical Service.

16.1 Monitor and Controller Interface



Label	Description	Function
A	HIGH TEMP lamp	Indicates when the freezer is in a high temperature alarm condition. Also indicates high alarm temperature setpoint is being changed.
B	LOW TEMP lamp	Indicates when the freezer is in a low temperature alarm condition. Also indicates low alarm temperature setpoint is being changed.
C	DOOR ALARM lamp	Indicates when the door is open.
D	COOL lamp	Indicates the compressor is running.
E	SET lamp	Indicates when temperature setpoint or alarm setpoint is being changed.
F	Display	Displays real-time temperature information, setpoints, and alarms.
G	SEL button	Toggles between alarm monitor and control modes.
H	CONTROL lamp	Indicates when the reading from the temperature probe is displayed.
I	MONITOR lamp	Indicates when the display is showing temperature readings from the chamber probe. Also indicates when alarm setpoints are being changed.
J	UP ARROW button	Increases a temperature setting.
K	DOWN ARROW / MUTE ALARM button	Decreases a temperature setting. Also mutes the audible alarm for five minutes.
L	SET button	Allows settings to be selected, prior to changing settings.

NOTE The Alarm Disable key switch disables all audible alarms. This switch does not affect alarm lamps or signals sent through the remote alarm interface.

16.2 Freezer Setpoint

NOTE Default setpoint is -30.0 °C.

Change the setpoint if:

- ▶ Your organization requires a chamber temperature other than -30.0 °C.
- ▶ The normal chamber temperature is too high or low (after completing preventive maintenance and applicable troubleshooting tasks).

Confirm:

- ▶ Freezer has been placed per location requirements in the operation manual.
- ▶ Preventive maintenance has been completed per operation manual.
- ▶ Troubleshooting items associated with chamber temperature have been reviewed (if necessary).

Change setpoint.

- 1 Determine the change in value to reach desired setpoint. Adjustment should be the difference between current setpoint and new setpoint.

EXAMPLE

- ▶ Current setpoint is -30.0 °C
- ▶ Target setpoint is -28.0 °C
- ▶ Setpoint adjustment value is +2.0 °C

- 2 On the monitoring system, press and release **SEL** to change to Control mode. CONTROL lamp will illuminate.
- 3 Press and hold **SET** to display the reference temperature.
- 4 Hold **SET** and press **Up Arrow** and **Down Arrow** as necessary to set the adjustment value determined in step 2.
- 5 Release all buttons; the setpoint is changed.
- 6 Press and release **SEL** to return to Monitor mode. MONITOR lamp will illuminate.

16.3 Temperature Alarm Setpoints

View setpoints:

- 1 Hold **Up Arrow** and **Down Arrow** for three seconds. MONITOR lamp will flash to indicate entry into program mode.
- 2 Press **SEL** until desired setting appears.
- 3 Observe the setting.
- 4 To view another setting, press **SEL** again (optional).
- 5 Hold **Up Arrow** and **Down Arrow** for three seconds. MONITOR lamp stops flashing to indicate exit from program mode.

Flashing Lamp	Selected Setting
HIGH TEMP and MONITOR	High temp alarm setpoint
LOW TEMP and MONITOR	Low temp alarm setpoint
MONITOR only	Monitor offset
CONTROL only	Control sensor offset
CONTROL only	Control hysteresis



NOTICE The Low Alarm Setpoint is not used in Helmer freezers.

16.3.1 High Temperature Alarm

- ▶ Specifies the temperature at which the High Temperature Alarm activates.
- ▶ Default setpoint is -20.0 °C.
- ▶ Setpoint can be changed from -40.0 °C to 0.0 °C.

Change the setpoint:

- 1 Hold **Up Arrow** and **Down Arrow** for three seconds. MONITOR lamp will flash to indicate entry into program mode.
- 2 Press **SEL** until HIGH TEMP and MONITOR lamps flash.
- 3 Hold **SET**, then press **Up Arrow** or **Down Arrow** to change the setpoint.
- 4 Release **SET** button.
- 5 Hold **Up Arrow** and **Down Arrow** for three seconds. MONITOR lamp stops flashing to indicate exit from program mode. New settings are saved.

16.3.2 Low Temperature Alarm



NOTICE The Low Alarm Setpoint is not used in Helmer freezers.

16.4 Temperature Calibration Setpoints

View setpoints:

- 1 Hold **UP Arrow** and **Down Arrow** for three seconds. MONITOR lamp will flash to indicate entry into program mode.
- 2 Press **SEL** until desired setting appears.
- 3 Observe the setting.
- 4 To view another setting, press **SEL** again (optional).
- 5 Hold **Up Arrow** and **Down Arrow** for three seconds. MONITOR lamp stops flashing to indicate exit from program mode.

Flashing Lamp	Selected Setting
HIGH TEMP and MONITOR	High temp alarm setpoint
LOW TEMP and MONITOR	Low temp alarm setpoint
MONITOR only	Monitor offset
CONTROL only	Control sensor offset
CONTROL only	Control hysteresis

16.4.1 Monitor Offset

- ▶ Adjust if temperature displayed on the monitor does not match measured chamber temperature.
- ▶ Value is factory-set to match an independent thermometer.
- ▶ Value can be changed from -10.0 °C to +10.0 °C.

NOTE

- ▶ If the variance is within acceptable limits, changing the offset value is optional.
- ▶ Probes in the bottle are connected to the monitoring system and sense chamber temperature. These probes do not affect freezer setpoint.

Obtain:

- ▶ Independent thermometer, calibrated and traceable per national standards.
- ▶ Tape, to attach thermometer to temperature probe.

Measure the chamber temperature:

- 1 Remove the probe from the probe bottle.
- 2 Unscrew the cap from the bottle.
- 3 Tape the thermometer to the temperature probe, and place them in the bottle. The probe and thermometer should be immersed at least 2" (50 mm).
- 4 Close the door and allow the chamber temperature to stabilize for 10 minutes.
- 5 Observe and note the thermometer temperature.
- 6 Lower the Offset Value to lower displayed monitor temperature; raise the Offset Value to raise displayed monitor temperature.

EXAMPLE

- ▶ Measured temperature (at the probe bottle) is -30.0 °C
- ▶ Displayed temperature is -28.0 °C
- ▶ Offset adjustment value is -2.0 °C

- 7 Remove thermometer and probe from bottle and remove tape.
- 8 Replace the probe in probe bottle.
- 9 Replace bottle cap, ensuring a tight fit.
- 10 Place the probe in bottle, immersing at least 2" (50 mm).

Enter the new offset value:

- 1 Hold **Up Arrow** and **Down Arrow** for three seconds. MONITOR lamp will flash to indicate entry into program mode.
- 2 Press **SEL** until only the MONITOR lamp flashes.
- 3 Hold **SET**, then press **Up Arrow** or **Down Arrow** to change the setpoint.
- 4 Release **SET** button.
- 5 Hold **Up Arrow** and **Down Arrow** for three seconds. MONITOR lamp stops flashing to indicate exit from program mode. New settings are saved.

16.4.2 Control Sensor Offset

The temperature controller senses chamber temperature through a probe in the unit cooler. The chamber setpoint typically varies from the measured temperature, so an offset value is used by the control system to compensate for the difference.

- ▶ Value is factory-preset and varies for each unit
- ▶ Offset value can be changed from -10.0 °C to +10.0 °C



NOTICE Control Sensor Offset is factory-preset and should not be changed unless directed by Helmer Technical Service.

NOTE If the variance is within acceptable limits for your organization, changing the offset value is optional.

16.4.3 Hysteresis

- ▶ Default setpoint is 2.0 °C
- ▶ Allowable temperature variance on each side of the freezer setpoint.



NOTICE Hysteresis is factory-preset and should not be changed unless directed by Helmer Technical Service.

16.5 Test Alarms

Test alarms to ensure they are working correctly. The freezer has alarms for chamber temperature, power failure, and door open (time).



NOTICE Before testing alarms, protect items in freezer from extended exposure to adverse temperature.

16.5.1 Chamber Temperature Alarm
Obtain:

- ▶ Independent thermometer, calibrated and traceable per national standards
- ▶ (1) 4 oz. (120 mL) glass of product simulation solution (1:1 ratio of water to propylene glycol or equivalent low-temperature fluid).



NOTICE Temperature probes are fragile; handle with care.

Test the high alarm:

- 1 Identify setting for high alarm setpoint.
- 2 Immerse the independent thermometer in the glass of product simulation solution.
- 3 Place the glass in the freezer and close the door.
- 4 When the glass contents have stabilized at the chamber temperature, remove the glass from the freezer.
- 5 While stirring probe in product simulation solution, allow the glass contents to warm up to room temperature and observe the temperature on the monitor.
- 6 When high temperature alarm is activated, note the temperature on the independent thermometer.
- 7 Remove the probe from the glass.
- 8 Place probe in probe bottle, immersing it at least 2" (50mm).
- 9 Compare the temperature at which the alarm is activated to the high alarm setpoint. If values do not match, calibrate the temperature monitor.

16.5.2 Power Failure Alarm

- 1 Switch AC ON/OFF switch **OFF**. Audible power failure alarm will activate immediately and "PoFF" (power off) will appear on the display.
- 2 Switch AC ON/OFF switch **ON**. Audible power failure alarm will cease and "PoFF" will clear from the display.

16.5.3 Door Open Alarm

- ▶ Factory-set to three minutes.
- ▶ Value can not be changed.

Test the alarm:

- 1 Open freezer door and note the time.
- 2 After three minutes, audible alarm will activate and DOOR ALARM lamp will flash.
- 3 Close freezer door. Audible door open alarm will cease and DOOR ALARM lamp will stop flashing.

17 Maintenance



- NOTICE**
- ▶ Before performing maintenance, protect items in freezer from extended exposure to adverse temperature.
 - ▶ Allow freezer temperature to stabilize at setpoint after performing service or after extended door opening.

NOTE Refer to the operation manual for the preventive maintenance schedule.

17.1 Recharge Refrigerant



- CAUTION**
- ▶ Review all safety instructions prior to recharging refrigerant. Refer to chapter 2 (Safety).
 - ▶ Maintenance should only be performed by trained refrigeration technicians.



NOTICE Use only non-CFC R-404A refrigerant.

Full initial refrigerant charge varies by model and power requirements, which can be found on the product specification label.

Model	Initial Charge
105	11.0 oz. (312 g)

Obtain:

- ▶ Refrigerant
- ▶ Calibrated pressure gauge (0 psi to 220 psi (0 kPa to 1520 kPa))

Add refrigerant:

- 1 Attach pressure gauge to the fittings on the refrigeration lines.
- 2 Monitor the low side (suction) pressure through a full compressor cycle.
- 3 Measure the pressure at the end of the next cycle, immediately before the compressor stops.

NOTE Pressure varies depending on ambient air temperature.

- 4 Add refrigerant. Check the pressure on the low side and high side.
 - ▶ Low side = 4 psi to 7 psi (30 kPa to 50 kPa)
 - ▶ High side = 180 psi to 220 psi (690 kPa to 1520 kPa)
- 5 Remove pressure gauge.

17.2 Test Monitoring System Battery

The monitoring system does not indicate the charge level of the battery. Regularly test the battery. Replace battery if the test fails or if the battery has been in use for one year.

Test the battery:

- 1 Switch the AC ON/OFF switch **OFF**.
 - a Display should continue to display information.
 - b If the display is blank, replace battery.
- 2 Switch AC ON/OFF switch **ON**.



NOTICE When installing a replacement battery, use only a battery which meets the specifications outlined in chapter 17.5 (Supplies).

17.3 Clean the Freezer

17.3.1 Condenser Grill

In environments where freezer is exposed to excessive lint or dust, condenser grill may require cleaning more frequently than stated in preventive maintenance schedule.

Clean the condenser grill using a soft brush and a vacuum cleaner.

17.3.2 Exterior

Clean exterior surfaces with soft cotton cloth and non-abrasive liquid cleaner.

17.3.3 Interior

Clean painted surfaces with mild detergent. Clean stainless steel surfaces with a general-purpose laboratory cleaner suitable for stainless steel.

17.3.4 Door Gaskets

Clean with soft cloth and mild soap and water solution.

17.3.5 Clean and Refill Probe Bottle

NOTE A kit that includes a probe bottle and propylene glycol is available from Helmer.

Obtain:

- ▶ Fresh water-bleach solution (not provided)
 - ▶ 1:9 ratio of bleach to water
 - ▶ Bleach is 5% solution of commercial sodium hypochlorite (NaOCl)
 - ▶ Equivalent oxidizing cleaner/disinfectant approved by your organization may be substituted
- ▶ 4 oz. (120 mL) of product simulation solution per bottle
 - ▶ 1:1 ratio of water to propylene glycol (or equivalent low-temperature fluid)

Clean and refill bottle:


- 1 Remove probe from bottle.
- 2 Remove bottle from bracket.
- 3 Clean bottle with water-bleach solution.
- 4 Fill bottle with 4 oz. (120 mL) of product simulation solution.
- 5 Cap bottle tightly to minimize evaporation.
- 6 Place bottle in bracket.
- 7 Replace probe, immersing at least 2" (50 mm).

17.4 Unit Cooler Cover Removal and Installation

If unit cooler cover is not removed as detailed in this procedure the drain port may be damaged. Improper drainage may result in excessive icing and freezer's inability to maintain temperature.

Required tools:

- ▶ 5/16" socket wrench
- ▶ #2 Phillips screwdriver
- ▶ Tool to push putty away from the drain hose



Drain line, fan, and heater components.

Label	Description
A	Unit cooler cover
B	Drain port
C	Drain fan
D	Fan tube
E	Heating element
F	Heater wires
G	Protective cover
H	Drain tube

17.4.1

Remove the Unit Cooler Cover



CAUTION Disconnect freezer from AC power when removing the unit cooler cover.

- 1 Switch AC ON/OFF switch **OFF**. Disconnect the monitoring system backup battery.
- 2 Remove the rear protective cover (G) on the rear of the cabinet.
 - a Using a #2 Phillips screwdriver, loosen four screws securing the cover to the cabinet.
 - b Slide the cover up and remove it from the cabinet.
 - c Cut the wire ties securing the drain line to the cabinet.
- 3 On the back of the cabinet, peel the putty back to expose the drain tube (H) and drain heater (E).



CAUTION The condensate evaporator and water evaporation tray are hot.

- 4 Inside the cabinet, remove the putty around the drain tube.
- 5 Remove the wire ties securing the heater wires (F) to the cabinet. Verify the heating element is cool.
- 6 Remove the drain heater from the drain tube.
- 7 Remove the drain tube (H) by pulling it downward. The drain tube should separate from the fan tube (D) at the 90° elbow, leaving the fan tube (D) attached to the fan (C).
 - a The section of the drain tube inside the cabinet should separate from unit cooler drain port (B).
 - b Gently twist the drain tube from left to right to separate it from the unit cooler drain port.
 - c Pivot the drain tube upward then remove it from the cabinet.
- 8 Remove top drawer, basket, or shelf from the chamber.

- 9 Remove the unit cooler cover (A).
 - a Hold unit cooler cover in place to prevent it from dropping.
 - b Use the socket wrench to remove four screws securing the unit cooler cover.
 - c Carefully lower unit cooler cover to avoid damage to the fan wiring.

17.4.2

Install the Unit Cooler Cover

- 1 Verify unit cooler wiring is connected and routed correctly.
 - a Wiring should be routed above copper tube inside the unit cooler.
 - b Reconnect wires if they have separated.
- 2 Attach unit cooler cover.
 - a Lift unit cooler cover into place.
 - b Front edge of the cover should be behind the unit cooler case.
 - c Use the socket wrench to install four screws to secure the unit cooler cover.
- 3 Insert the drain tube through hole in the cabinet.
 - a Push drain tube upward at an angle, toward the unit cooler drain port.
 - b Picot the drain tube downward then push the tube upward.
 - c In the chamber, push the drain tube onto unit cooler drain port.
- 4 Attach the drain tube to the fan tube.
- 5 Insert the drain line heater in the drain tube.
 - a Insert the heater at an upward angle.
 - b The black heating element should no longer be visible.
- 6 Reinstall top drawer, basket, or shelf if previously removed.
- 7 Reattach the drain line heater wires to the cabinet.
- 8 On the back of the cabinet, press putty around the drain hose and partially into the hole.
- 9 Install the protective cover on the rear of the cabinet.
- 6 Switch AC ON/OFF switch **ON**. Reconnect the monitoring system backup battery.
- 7 Press the **MUTE** button to disable the high temperature alarm while freezer reaches operating temperature.

17.5

Supplies

Refrigerant: non-CFC, R-404A

Chart paper: 220419 (52 sheets)

Propylene glycol solution: 400922-2

Monitoring system backup battery: (1) 9 V non-rechargeable lithium (or equivalent)

Chart recorder backup battery (optional): (1) 9 V non-rechargeable alkaline (or equivalent)

18 Troubleshooting



- CAUTION**
- ▶ Review all safety instructions prior to troubleshooting. Refer to chapter 2 (Safety).
 - ▶ Troubleshooting should only be performed by trained refrigeration technicians.

18.1 General Operation Problems

Problem	Possible Cause	Action
A drawer does not slide easily.	Drawer slide is faulty.	▶ Confirm the slide is operating correctly. Replace if necessary.
	Debris in the drawer slides.	▶ Pull the drawer out and confirm the slides are free of debris. Clean if necessary.
	Ice buildup in the drawer slides.	▶ Pull the drawer out and confirm the slides are free of ice. De-ice and clean if necessary.
	Drawer slides are not lubricated.	▶ Using a lightweight oil, lubricate the bearings in the slides.
	Drawer is misaligned or not level.	▶ Confirm both slides for the drawer are mounted at the same height.
Door does not open easily.	Debris in the hinges.	▶ Confirm the hinges are free of debris. Clean the hinges if necessary.
	Door hinges are not lubricated.	▶ Using a general-purpose grease, lubricate the pivots in the hinges.
	Lower hinge spring and/or pin may be bent or faulty.	▶ Confirm the hinge spring and pin assembly is not damaged. Replace entire hinge if necessary.

18.2 Chamber Temperature Problems

Problem	Possible Cause	Action
"Prob" (probe) appears on the display, but the chamber temperature is set correctly.	Connections for the chamber temperature probe are loose.	▶ Test the probe connections. Secure the connections if necessary.
	Temperature probe wiring is an open circuit.	▶ Check the continuity of the probe wiring and connections. Secure the connections or replace the probe if necessary.
An error code displays on the monitor.	A component is faulty or internal connections are loose.	▶ Contact a qualified service technician.
Chamber temperature meets an alarm condition, but the appropriate temperature alarm is not active.	Temperature alarm setpoint was changed.	▶ Check the current setpoints for the temperature alarms. Change the setpoints if necessary.

Problem	Possible Cause	Action
Chamber temperature does not stabilize at the freezer setpoint.	Condenser grill is dirty.	▶ Check the condenser grill. Clean it if necessary.
	Circulation in the chamber is not adequate.	▶ Check if there are any items obstructing air flow and remove them if necessary.
	Ambient air temperature around the freezer is too high.	▶ Confirm the freezer is placed appropriately.
	A component is faulty or internal connections are loose.	▶ Contact a qualified service technician.
	Compressor starting relay is faulty.	▶ Confirm the relay is operating correctly. Replace the relay if necessary.
	Monitor/control board is faulty.	▶ Confirm monitor/control board or temperature/defrost controller is operating correctly. Replace the board or controller if necessary.
	Compressor fan is not running.	▶ Check the compressor fan connections. Replace the fan motor if necessary.
	Unit cooler fan is not running.	▶ Activate the door switch, wait for the fan delay to elapse (about 15 to 30 seconds), then check the voltage to the fan. Replace the fan motor or door switch if necessary.
	Refrigerant level is too low.	▶ Check the refrigerant level. Recharge the refrigerant if necessary.
	Compressor motor has seized.	▶ Replace the compressor.
	Temperature control probe is faulty.	▶ Confirm the probe is providing resistance in the range of 1191 Ω to 2000 Ω . Replace the probe if necessary.

18.3

Alarm Activation Problems

Problem	Possible Cause	Action
Freezer is in an alarm condition, but alarms are not audible.	A component is faulty or internal connections are loose.	▶ Confirm the circuit board and line connections are functioning correctly.
	Alarm buzzer is faulty.	▶ Replace the alarm buzzer.
	Alarm Disable key switch is turned OFF.	▶ Turn key switch to the ON position.
	Audible alarms have been muted.	▶ Verify audible alarms are not muted.
An alarm activated, but the temperature recorded at activation does not match the alarm setpoint.	Temperature changed slightly around the time of activation.	▶ No action needed.

Problem	Possible Cause	Action
Freezer is connected to outlet power, but the Power Failure alarm is active.	Outlet connection is faulty.	▶ Verify power at the outlet. Repair the outlet or connect to a different outlet.
	Power cord is faulty.	▶ Confirm the cord is connected securely. Secure cord if necessary.
	Lower front panel AC power switch is OFF.	▶ Turn AC power switch ON.
	A component is faulty or internal connections are loose.	▶ Contact a qualified service technician.
Door Open alarm is activating sporadically.	Door is not closing completely.	▶ Confirm the lower hinge and/or spring is not damaged. Check/change tension. Replace if necessary. ▶ Confirm door is aligned.
	Door is closing but not sealing completely.	▶ Confirm the door gasket seals completely. Replace the door gasket if necessary.
	Connections for the door switch are faulty.	▶ Test the switch connections. Secure the connections if necessary.
	Door switch is faulty.	▶ Replace the door switch.
All alarms are activating sporadically.	Alarm system is faulty.	▶ Confirm the circuit board and line connections are functioning correctly.
	A component is faulty or internal connections are loose.	▶ Contact a qualified service technician.
High Temperature alarm activates when the door is opened, then clears shortly after the door is closed.	Probe bottle is empty.	▶ Check the level of product simulation solution in the bottle. Refill the bottle if necessary.
	High temperature alarm setpoint is set too low.	▶ Check the setpoint. Change the setpoint if necessary.
	A component is faulty or internal connections are loose.	▶ Contact a qualified service technician.

18.4 Condensation Problems

Problem	Possible Cause	Action
After defrosting, no water flows into the water evaporation tray.	Not enough time has elapsed since the end of the defrost cycle.	<ul style="list-style-type: none"> ▶ Wait until approximately 20 minutes after the defrost cycle has ended.
	Drain line is plugged.	<ul style="list-style-type: none"> ▶ Confirm the drain tube is free of debris. Remove debris if necessary.
	Drain line heater is not working.	<ul style="list-style-type: none"> ▶ Confirm the connections are secure. Tighten the connections if necessary. ▶ Confirm the drain line heater is warm to the touch. ▶ Replace the heater if necessary.
	Defrost heater on the evaporator in the unit cooler is not working.	<ul style="list-style-type: none"> ▶ Check for ice buildup on the evaporator. Shine a flashlight into the fan opening on the unit cooler and check for ice buildup. Also, feel behind the unit cooler for ice buildup. If there is significant ice buildup in either area, defrost the freezer.
	Defrost heater on the evaporator in the unit cooler is faulty.	<ul style="list-style-type: none"> ▶ After defrosting the freezer, monitor the evaporator for repeated ice buildup. ▶ Confirm the connections are secure. Tighten the connections if necessary. ▶ Confirm the defrost heater is hot and is drawing the appropriate current during a defrost event (approximately 3.9 A to 5.5 A). ▶ Replace the heater if necessary.
Excessive humidity on the door.	Humid air is entering the chamber.	<ul style="list-style-type: none"> ▶ Confirm the freezer is level, and the doors are aligned, closing tightly, and sealing correctly. Contact a qualified service technician to correct issues as necessary.
	Relative humidity around the freezer is too high.	<ul style="list-style-type: none"> ▶ Confirm the freezer is placed appropriately.
Excessive ice in the chamber.	Humid air is entering the chamber.	<ul style="list-style-type: none"> ▶ Confirm the freezer is level, and the doors are aligned, closing tightly, and sealing correctly. Correct issues as necessary.
	Drain port on the unit cooler was damaged during removal of the unit cooler cover.	<ul style="list-style-type: none"> ▶ Confirm the drain port on the unit cooler is intact.
	External fan is faulty.	<ul style="list-style-type: none"> ▶ Confirm the external drain fan is running. Hold a piece of paper in front of fan and check that the paper is being drawn toward the freezer. ▶ Confirm the connections are secure. Tighten the connections if necessary. ▶ Replace the external drain fan.

19 Parts





NOTICE

- ▶ Before replacing parts, protect items in freezer from extended exposure to adverse temperature.
- ▶ Allow freezer temperature to stabilize at setpoint after replacing parts or after extended door opening.

19.1 Front

19.1.1 Control System Display



Top: Horizon Series combined controller and monitor. Bottom: Horizon Series display circuit board.

Label	Description	Part Number	Schematic Label
A	Monitor with touchpad (display)	400838-1	AZ
B	Control and monitor board kit	400837-1	L



NOTICE


The display board is sensitive to static electricity and can be damaged by electrostatic discharge. Use proper ESD precautions when handling the board.

19.1.2 Control and Monitoring



Label	Description	Part Number	Schematic Label
A	Horizon Series monitoring and control system		-
B	Temperature chart recorder (standard on plasma freezer model, optional on laboratory / pharmacy model)		-
C	Chart paper (52 sheets)	220419	-
Not shown	Chart recorder backup battery	120218	-


19.1.3 Lower Panel



Front panel features.

Label	Description	Part Number	Schematic Label
A	Condenser	-	-
B	Monitoring system backup battery	120399	AE
C	Alarm disable key switch	-	M
D	Main power switch	120478	Q

19.2 Rear



Rear features.

Label	Description	Part Number	Schematic Label
A	Nut flanges for brace bars used in stacking undercounter units (four shown)	-	-
B	Rear access port	-	-
C	Drain line (copper tube segment)	400910-1	-
D	Product specification label	-	-
E	Power cord connector	120299	-
F	External drain fan		Z
G	Compressor/component rear compartment door	321184-1	-
H	Remote alarm contacts	-	-
I	Power cord	-	-
J	Condensate evaporator tray	-	-
K	Compressor	Contact Helmer	A
L	Condensing unit fan motor	Contact Helmer	U
Not shown	Compressor solid state relay	400842-1	AA
	Defrost timer	800015-1	F
	Caster (optional, swivel with brake)	220380	-

19.2.1 Electrical Tray

Kick plate (removed). Pull-out electrical components tray (open).



WARNING Disconnect the freezer from AC power before accessing the electrical tray.



NOTICE The control board is sensitive to static electricity and can be damaged by electrostatic discharge. Use proper ESD precautions when handling the board.

19.3


Interior



Interior features.

Label	Description	Part Number	Schematic Label
A	Door	Solid door Stainless steel: 400918-1 Powder coated: 400918-2	-
B	Drawer (plasma storage models)	400584-3	-
C	Door switch	120380	M
D	Roll-out basket (optional)	400890-3	-
E	Standard for shelf, drawer, or roll out basket	321173-1	-
F	Chamber temperature probe	400512-1	AB
G	Drawer slide for drawer or roll out basket	Left: 400541-6 Right: 400541-5	-
H	Probe bottle and propylene glycol kit	400922-2	-
I	Shelf (laboratory / pharmacy model)	400814-1	-

19.3.1 Unit Cooler



Left: Unit cooler with fan guard. Middle: Unit cooler fan. Right: Temperature control probe.

Label	Description	Part Number	Schematic Label
A	Unit cooler	-	-
B	Fan guard	-	-
C	Unit cooler fan	120540	H
D	Temperature control probe	400511-2	G

19.4 Door Hinges



Hinge, hinge spring and pin assembly, and door handle with key lock.

NOTE Spring tension is controlled at the point where the pin is stopped by the side plate (C, D).

Label	Description	Part Number
A	Hinge, covered, edge mount	220506
B	Hinge, uncovered, without spring assembly	-
C	Hinge, uncovered, spring and pin assembly	-
D	Close up, hinge spring and pin assembly	-
E	Door handle - Magnetic offset latch with key lock	220426
F	Door key lock with key, close-up	-

19.5 Side Access Panel


Undercounter freezers feature easy access for servicing, removal, and replacement of the compressor and condenser. The compressor is accessible from the rear and the side.




Side access panel.

20 Schematics

20.1 Horizon Series Schematic



HORIZON SERIES,
UNDERCOUNTER
FREEZER



END OF MANUAL

HELMER SCIENTIFIC
14400 Bergen Boulevard
Noblesville, IN 46060 USA

PH +1.317.773.9073
FAX +1.317.773.9082
www.helmerinc.com

